



2007
Precedent Golf Car
Illustrated Parts List



Gasoline and Electric Vehicles

Manual Number 103209001
Edition Code 0507P0112N

USING THE ILLUSTRATED PARTS LIST

WARNING

- **This manual is to be used only for identification and ordering of service parts. Be sure to read and use the maintenance and service manual before attempting any vehicle repairs.**

This manual covers all 2007 Club Car® Precedent® Professional and Champion vehicles.

The manual is divided into 17 sections. Sections 1 through 5 pertain to both gasoline and electric vehicles, sections 6 through 12 pertain to gasoline vehicles only, sections 13 through 16 pertain to electric vehicles only, and section 17 pertains to tools that are used on all Club Car products. Note that there are two or three flags on the outside edge of each page. The first flag contains the section number of which that page is a part. The other flag (or flags) contains either the letter G or E, signifying that the page pertains to either the gasoline or electric vehicle only, or to both the gasoline and electric vehicles.

Use the Table of Contents to find the sections and pages that contain the parts and assemblies you seek. The Table of Contents lists section numbers, and under them, the individual page titles and numbers to be found in that section. The index can be used to find specific parts and assemblies. The index is divided into numerical and alphabetical listings with the page numbers in italic text.

There is a two-page spread for each individual page title in the Table of Contents. On the left-hand page is an illustration showing the parts in their relative positions; the parts are each tagged with an item number in a balloon. The right-hand page is the parts list page, and gives the page title at the top, then the item numbers (corresponding to the numbers on the illustration), part descriptions, and quantity of parts used. Some item numbers have more than one part number because several configurations of a component are represented together on one spread.

Note that a part description may be indented. This indentation corresponds to a parts assembly level indicated by the numbers 1, 2, 3, and 4 at the top left corner of the parts description area of the parts list page. A part that is indented to *level 2* is a component of the *level 1* part (assembly) that it is listed under. A *level 3* part is a component of the *level 2* part that it is listed under, and a *level 4* part is a component of the *level 3* part preceding it. In each case, the part quantity given for a level 2, 3, or 4 part is *the quantity used per next higher level assembly of which it is a component*. A part that is not indented is a *level 1* part. This means that the quantity given is the quantity used per the portion of the vehicle illustrated on that particular spread.

HOW TO ORDER PARTS

Replacement parts and accessories can be obtained from our network of authorized dealers and distributors. You can obtain the name and phone number of your closest authorized Club Car dealer or distributor by visiting our web site at www.clubcar.com and clicking on the "Distributor Search" link or by calling our toll-free Service Parts and Technical Assistance hotline at (800) 872-2246 or (706) 863-3000, extension 3887.



P. O. Box 204658
Augusta, Georgia 30917-4658 USA
Telephone 706-863-3000
Service Parts Fax 706-855-7413
www.clubcar.com

NOTE: *This illustrated parts list represents the most current information at the time of publication. Club Car, Inc. is continually working to further improve its vehicles and other products. These improvements may affect the parts used to service the vehicle. Any modification and/or significant change in specifications will be forwarded to all Club Car and Carryall distributors/dealers and will, when applicable, appear in future editions of this illustrated parts list.*

Club Car, Inc. reserves the right to change specifications and designs at any time without notice and without the obligation of making changes to units previously sold.

Copyright © 2007 Club Car, Inc.
Club Car, Precedent, and Surlyn
are registered trademarks of Club Car, inc.
This manual effective July 31, 2006.

2007 Precedent Gasoline and Electric Vehicle Illustrated Parts List

CONTENTS

SECTION 1 – BODY AND TRIM

Front Bumper	1-3
Front Body	1-5
Dash – Style A	1-7
Floor Mat, Retainer, and Front Underbody – Style B	1-9
Kick Plate – Gasoline Vehicle	1-11
Kick Plate – Electric Vehicle	1-13
Seat with Hip Restraints	1-15
Backrest and Structural Accessory Module (SAM)	1-17
Rear Body	1-19
Underbody Covers (Vehicle Without Canopy)	1-21
Canopy Snap-In Drain Cover	1-23
Canopy – Beige	1-25
Canopy – White	1-27
Rear Seat – Precedent Villager 4	1-29
Rear Footrest Assembly – Precedent Villager 4	1-31
Four Passenger Conversion Kit – Beige	1-33
Four Passenger Conversion Kit – White	1-35
Four Passenger Conversion Kit – Gray	1-37

SECTION 2 – WHEEL AND TIRES

Wheels and Tires – Professional	2-3
Wheels and Tires – Champion	2-5

SECTION 3 – DECALS

Decals – Gasoline Vehicle	3-3
Decals – Electric Vehicle	3-5
Decal – Precedent Villager 4	3-7

SECTION 4 – BRAKES AND PEDAL GROUP ASSEMBLIES

Rear Brake Assembly, Self-Adjusting	4-3
Brake Cables	4-5
Pedal Group Connections – Gasoline Vehicle	4-7
Pedal Group Connections – Electric Vehicle	4-9
Pedal Group Components – Gasoline Vehicle	4-11
Pedal Group Components – Electric Vehicle	4-13

CONTENTS

SECTION 5 – STEERING, FRONT AND REAR SUSPENSION

Steering Wheel – Champion	5-3
Steering Wheel – Professional	5-5
Steering Column	5-7
Steering Column – Electric Vehicles	5-9
Steering Gear Assembly	5-11
Front Suspension, Upper	5-13
Front Suspension, Lower	5-15
Rear Suspension – Gasoline Vehicle	5-17
Rear Suspension – Electric Vehicle	5-19
Rear Suspension – Precedent Villager 4	5-21

SECTION 6 – ELECTRICAL SYSTEM – GASOLINE VEHICLE

Electrical Components, Front Body – Gasoline Vehicle	6-3
Battery – Gasoline Vehicle	6-5
Wiring – Gasoline Vehicle	6-9
Instrument Panel Wire Harness	6-13
Starter/Generator Assembly Model G425419 – Gasoline Vehicles	6-15
Starter/Generator Mounting – FE350	6-17

SECTION 7 – AS11 FE350 ENGINE

AS11 FE350 Engine without ACR (Automatic Compression Release) – Shrouds and Brackets	7-3
AS11 FE350 Engine – Ignition Components and Flywheel	7-5
FE350 Engine – Oil Circulation	7-7
AS11 FE350 Engine – Cylinder Head	7-9
AS11 FE350 Engine without ACR – Crankcase, Camshaft, and Oil Sensor	7-11
AS11 FE350 Engine – Crankcase and Crankshaft	7-13
FE350 Engine Mounting	7-15

SECTION 8 – FUEL, INTAKE, AND GOVERNOR SYSTEMS

Fuel System	8-3
Carburetor Assembly – FE350	8-5
Carburetor Installation – FE350	8-7
Governor and Accelerator Cables	8-9
Choke and Air Box Assembly	8-11

SECTION 9 – EXHAUST SYSTEM

Exhaust System – FE350	9-3
------------------------------	-----

CONTENTS

SECTION 10 – TORQUE CONVERTER

Drive Clutch	10-3
Drive Belt – FE290	10-5
Driven Clutch	10-7

SECTION 11 – UNITIZED TRANSAXLE

Unitized Transaxle – Gear Cases and Brackets	11-3
Unitized Transaxle – F&R Transmission and Gear Reduction	11-5
Transaxle – Gasoline Vehicles, Differential and Axles	11-7
Forward/Reverse Shifter Assembly – Gasoline Vehicle	11-9
Transmission Cable	11-11

SECTION 12 – ELECTRICAL SYSTEM – ELECTRIC VEHICLE

Electrical Components, Front Body – Electric Vehicle	12-3
Wiring – Electric Vehicle	12-7
Forward/Reverse Switch and Tow/Run Switch – Electric Vehicle	12-9
Single Point Watering System	12-11
Batteries, Bucket, and Charger Receptacle – Electric Vehicle	12-13
Computer, Controller, and Solenoid – Electric Vehicle	12-15

SECTION 13 – ELECTRIC MOTOR

Motor (Model 5BC59JBS6365) – Electric Vehicle	13-3
Motor (Model 5BC59JBS6390) – Electric Vehicle	13-5
Motor (Model EJ4-4001) – Electric Vehicle	13-7
Motor (Model EJ8-4001A) – Electric Vehicle	13-9

SECTION 14 – TRANSAXLE – ELECTRIC VEHICLES

Transaxle – Electric Vehicles	14-3
-------------------------------------	------

SECTION 15 – BATTERY CHARGER

PowerDrive 3 Battery Charger, Domestic	15-3
PowerDrive 2 Battery Charger (Model 22110), Domestic	15-5
PowerDrive Battery Charger (Model 17930), Domestic	15-7
PowerDrive Battery Charger (Model 18780), Export	15-9
PowerDrive Battery Charger (Model 20310), European	15-11

CONTENTS

SECTION 16 – MAINTENANCE AND SERVICE TOOLS

Maintenance and Service Tools	16-3
Maintenance and Service Tools, Continued	16-5
Maintenance and Service Tools, Continued	16-7
Maintenance and Service Tools, Continued	16-9
Maintenance and Service Tools, Continued	16-11

SECTION i – INDEX

BODY AND TRIM

1


G

E

1

G

E



000437-001

FRONT BUMPER

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	102298401	Nut,m8,all Metal Lock	2
2	102534201	Bolt - Fl Hd, M8 X 95	2
3	103330601	Asm, Bumper, Front, Precedent	1

1


G

E

1

G

E



000434-001


FRONT BODY

ITEM	PART NO.	DESCRIPTION	QTY	1	G	E
		1 2 3 4				
1	<u>102296020</u>	Screw, Torx Pan Hd Pt, M6 X 20	14			
2	<u>102501501</u>	Brow	1			
3	<u>102502401</u>	Panel, Beauty Front, White	1			
4	<u>102502402</u>	Panel, Beauty Front, Beige	1			
5	<u>102502404</u>	Panel, Beauty Front, Gray	1			
6	<u>102502405</u>	Panel, Beauty Front, Red	1			
7	<u>102502406</u>	Panel, Beauty Front, Burgundy	1			
8	<u>102502407</u>	Panel, Beauty Front, Green	1			
9	<u>102502408</u>	Panel, Beauty Front, Blue	1			
10	<u>102502409</u>	Panel, Beauty Front, Black	1			
11	<u>102502411</u>	Panel, Beauty, Front, Cayenne	1			
12	<u>102502413</u>	Panel-beauty Front, Atlantic	1			
13	<u>102502501</u>	Brow Cap	1			
14	<u>102534404</u>	Fascia, Blk	1			
15	<u>103816601</u>	Nameplate -cc	1			

1

G


E



000438-001

DASH – STYLE A

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>1010434</u>	Barrel - Plastic	2	
2	<u>102292356</u>	Screw-1/4-20x56 Hwh Self Drill	3	
3	<u>102296819</u>	Screw-m6 X 19-pnhd Ab	2	
4	<u>102380401</u>	Dash, Tray	1	
5	<u>102523101</u>	Dash Assembly	1	
6	<u>102557201</u>	Screw, #6-20 Type Abx1.00 Pan	1	
Note: Dash-style A should be used with front underbody-style A only. Underbody-style A is no longer available as a service part. If underbody needs to be replaced as well, order underbody-style B and dash-style B.				

1**G****E**

000497-001


FLOOR MAT, RETAINER, AND FRONT UNDERBODY – STYLE B

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>1010434</u>	Barrel - Plastic	2	
2	<u>102292356</u>	Screw-1/4-20x56 Hwh Self Drill	3	
3	<u>102292701</u>	Clip-body-trim	8	
4	<u>102296601</u>	U-nut, M6-1.0 Prev Torque	2	
5	<u>102296920</u>	Screw, M6 Torx Bttn Hd Sems	2	
6	<u>102298020</u>	Screw, K80x20, Torx Pn Hd Pt	4	
7	<u>102298716</u>	M8-1.25x16 Taptite	4	
8	<u>102302504</u>	Retainer Asm-floormat Rh, Blk	1	
9	<u>102302604</u>	Retainer Asm-floormat Lh, Blk	1	
10	<u>102504802</u>	Floormat, Precedent	1	
11	<u>102521901</u>	Bracket-clamshell	2	
12	<u>102523901</u>	Decal, IR/Club Car	2	
13	****	Asm-front Underbody, Black	1	
**** Special order item available upon request. Note: Underbody-style B should be used with dash-style B only.				

1

G

E



000501-001


KICK PLATE – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	1	G	E
		1 2 3 4				
1	<u>1014413</u>	Pin, Hair Spring Cotter	1			
2	102298030	Screw, K80x30, Torx Pn Hd Pt	3			
3	<u>102511702</u>	Asm-gas Kick Plate, Blk (includes items 4 through 6)	1			
4	<u>101811401</u>	Lever, Choke	1			
5	<u>101856201</u>	Compression Spring	1			
6	N/A	Plate - Gas Kick, Blk	1			
7	<u>102514401</u>	Rod, Choke Button	1			

1

G

E



000500-001


KICK PLATE – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
1	102298030	Screw, K80x30, Torx Pn Hd Pt	3
2	<u>102508202</u>	Plate - Electric Kick Blk	1
3	<u>102516901</u>	Socket Trim	1

1

G


E



000440-002

SEAT WITH HIP RESTRAINTS


ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>102562701</u>	Hip Restraint, Prec, Lh	1	
2	<u>102562801</u>	Hip Restraint, Prec, Rh	1	
3	<u>102562901</u>	Screw, Seat Bottom Prec	6	
4	<u>103423001</u>	Seat Bottom Asy, Prec-beige	1	
5	<u>103423002</u>	Seat Bottom Asy, Prec-white	1	
6	<u>103423004</u>	Seat Bottom Asy, Prec-gray	1	
7	<u>103447901</u>	Bracket, Hinge, Male, Prec	2	

1**G****E**

000435-001

BACKREST AND STRUCTURAL ACCESSORY MODULE (SAM)

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>102296530</u>	Screw - M6 X 1.0 X 30 Sems	2	
2	<u>102298240</u>	Bolt, Flange Head, M8-1.25 X 40	4	
3	<u>102503221</u>	Service Backrest Asm, Beige	1	
4	<u>102503222</u>	Service Backrest Asm, White	1	
5	<u>102503224</u>	Service Backrest Asm, Gray	1	
6	<u>102503225</u>	Service Backrest Asm-black	1	
7	<u>102503901</u>	Asm-sam (includes items 8 through 17)	1	
8	<u>102297125</u>	Screw M6-1.0x25.4 Thd Fm Sems	3	
9	<u>102504001</u>	Asm-bag Hoop (includes items 10 through 13)	1	
10	<u>1010434</u>	Barrel - Plastic	2	
11	<u>102504201</u>	Hoop-bag	1	
12	<u>102504301</u>	Strap, Bag	1	
13	<u>102517001</u>	Buckle-bag Strap	2	
14	<u>102504101</u>	Structural Accessory Module	1	
15	<u>102504501</u>	Panel, SAM	1	
16	<u>102551701</u>	Insert M6x1.0	4	
17	<u>103327601</u>	Screw, 5/16, Torx, Bosscrew	2	
18	<u>102568701</u>	Barrel - Plastic 6mm	8	

1**G****E**

000436-003

REAR BODY

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>102279001</u>	Rear Bumper Beam	1
2	<u>102279103</u>	Underbody - Rear, Grey	1
3	<u>102279104</u>	Underbody - Rear, Blk	1
4	<u>102292701</u>	Clip-body-trim	2
5	<u>102296601</u>	U-nut, M6-1.0 Prev Torque	2
6	<u>102297230</u>	Screw,m6,torx,interlock,thread	4
7	<u>102298030</u>	Screw, K80x30, Torx Pn Hd Pt	4
8	<u>102298240</u>	Bolt, Flange Head, M8-1.25 X 40	2
9	<u>102298580</u>	M8-1.25 X 80 Sems	4
10	<u>102298601</u>	J-clip - M8 X 1.25	4
11	<u>102298716</u>	M8-1.25x16 Taptite	2
12	<u>102500501</u>	Asm, Rear U/b Support, Lh	1
13	<u>102500601</u>	Asm, Rear U/b Support, Rh	1
14	<u>102501401</u>	Panel, Access, Gray	1
15	<u>102501402</u>	Panel, Access, Black	1
16	<u>102502301</u>	Panel, Beauty, Rear, White	1
17	<u>102502302</u>	Panel, Beauty, Rear, Beige	1
18	<u>102502304</u>	Panel, Beauty, Rear, Gray	1
19	<u>102502305</u>	Panel, Beauty, Rear, Red	1
20	<u>102502306</u>	Panel, Beauty, Rear, Burgundy	1
21	<u>102502307</u>	Panel, Beauty, Rear, Green	1
22	<u>102502308</u>	Panel, Beauty, Rear, Blue	1
23	<u>102502309</u>	Panel, Beauty, Rear, Black	1
24	<u>102502311</u>	Panel-beauty Rear, Cayenne	1
25	<u>102502313</u>	Panel-beauty Rear, Atlantic	1
26	<u>102502901</u>	Bracket, Canopy Support Left-Hand	1
27	<u>102503001</u>	Bracket, Canopy Support Right-Hand	1
28	<u>102967901</u>	Rivet, Removable, Tuflok 1/4"	2
29	N/A	Diverter, Precedent Water	1
30	<u>103677401</u>	Bracket, Bmpr, Pas	1
31	<u>103677402</u>	Bracket, Bmpr, Drv	1

1


G

E

1

G

E



000730-001

UNDERBODY COVERS (VEHICLE WITHOUT CANOPY)

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	102543902	Kit, Underbody Cover, Black (includes items 2 through 7)	1
2	102299065	M8-1.25 X 65 Tx Bttn Hd Bolt	4
3	102400202	Cover, Lh Non-canopy, Blk	1
4	102400302	Cover, Rh Non-canopy, Blk	1
5	102544001	Support, Strut Cover	2
6	102544101	SAM Cap	2
7	102544201	Screw, M6 Hex	4
Note: Sub-components contained in item 8 are the same as those shown for item 1, except for the color of the caps and covers.			

1


G

E

1

G

E



000439-002


CANOPY SNAP-IN DRAIN COVER

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
1	<u>102516301</u>	1 2 3 4 Drain Cover (Snap-In) Note: For use on canopies produced prior to mid-2007.	2	

1

G

E



000439-001


CANOPY – BEIGE

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>102520702</u>	Kit-canopy, Prec-beige (includes items 2 through 13)	1	
2	<u>102560202</u>	Beige Canopy Component Kit (includes items 3 through 6)	1	
3	<u>102400002</u>	Cover, Lh Canopy Support, Blk	1	
4	<u>102400102</u>	Cover, Rh Canopy Support, Blk	1	
5	<u>102513501</u>	Asm-rear Canopy Support	2	
6	N/A	Asm-canopy, Beige (includes items 7 through 12)	1	
7	<u>102296140</u>	Bolt, Flanged Head, M6x1.0x40	4	
8	<u>102296401</u>	Nut-m6x1.0 Flng All Mtl Lock	4	
9	<u>102508902</u>	Canopy-beige	1	
10	<u>102511602</u>	Handle, Canopy (Beige)	2	
11	<u>103205101</u>	Cover, Drain, Canopy, Precedent	2	
12	<u>103210101</u>	Screw, #8 X.75, Torx, Tapping	2	
13	<u>102560301</u>	Kit, Hardware, Canopy Strut (includes items 14 through 24)	1	
14	<u>102298401</u>	Nut,m8,all Metal Lock	2	
15	<u>102299065</u>	M8-1.25 X 65 Tx Bttm Hd Bolt	4	
16	<u>102299360</u>	Screw, M8-1.25 X 60, Sems, Tx	2	
17	<u>102299601</u>	Screw, Pt, K80x70 Hex Flg Hd	2	
18	<u>102512401</u>	Support, Canopy Front, Right-Hand	1	
19	<u>102513301</u>	Support, Canopy Front Left-Hand	1	
20	<u>102544201</u>	Screw, M6 Hex	2	
21	N/A	Instr, Kit, Canopy (prec)	1	
22	<u>103196001</u>	Washer, Conical Spring, Canopy	8	
23	<u>103199301</u>	Bolt - M6 X 1 X 45 Hh Grey	4	
24	<u>103200301</u>	Nut, M6 x 1.00	4	
Note: Item 21 not shown.				

1

G

E



000439-001


CANOPY – WHITE

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>102520701</u>	Kit-canopy, Prec-white (includes items 2 through 13)	1	
2	<u>102560201</u>	White Canopy Component Kit (includes items 3 through 6)	1	
3	<u>102400002</u>	Cover, Lh Canopy Support, Blk	1	
4	<u>102400102</u>	Cover, Rh Canopy Support, Blk	1	
5	<u>102513501</u>	Asm-rear Canopy Support	2	
6	N/A	Asm-canopy, White (includes items 7 through 12)	1	
7	<u>102296140</u>	Bolt, Flanged Head, M6x1.0x40	4	
8	<u>102296401</u>	Nut-m6x1.0 Flng All Mtl Lock	4	
9	<u>102508901</u>	Canopy-white	1	
10	<u>102511601</u>	Handle, Canopy (White)	2	
11	<u>103205101</u>	Cover, Drain, Canopy, Precedent	2	
12	<u>103210101</u>	Screw, #8 X.75, Torx, Tapping	2	
13	<u>102560301</u>	Kit, Hardware, Canopy Strut (includes items 14 through 24)	1	
14	<u>102298401</u>	Nut,m8,all Metal Lock	2	
15	<u>102299065</u>	M8-1.25 X 65 Tx Bttm Hd Bolt	4	
16	<u>102299360</u>	Screw, M8-1.25 X 60, Sems, Tx	2	
17	<u>102299601</u>	Screw, Pt, K80x70 Hex Flg Hd	2	
18	<u>102512401</u>	Support, Canopy Front, Right-Hand	1	
19	<u>102513301</u>	Support, Canopy Front Left-Hand	1	
20	<u>102544201</u>	Screw, M6 Hex	2	
21	N/A	Instr, Kit, Canopy (prec)	1	
22	<u>103196001</u>	Washer, Conical Spring, Canopy	8	
23	<u>103199301</u>	Bolt - M6 X 1 X 45 Hh Grey	4	
24	<u>103200301</u>	Nut, M6 x 1.00	4	
Note: Item 21 not shown.				

1

G

E



000494-001


REAR SEAT – PRECEDENT VILLAGER 4

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>1010434</u>	Barrel - Plastic	10	
2	<u>102296530</u>	Screw - M6 X 1.0 X 30 Sems	4	
3	<u>102298030</u>	Screw, K80x30, Torx Pn Hd Pt	2	
4	<u>102298240</u>	Bolt, Flange Head, M8-1.25 X 40	1	
5	<u>102298720</u>	M8-1.25x20 Taptite	10	
6	<u>102503221</u>	Service Backrest Asm, Beige	1	
7	<u>102503222</u>	Service Backrest Asm, White	1	
8	<u>102503224</u>	Service Backrest Asm, Gray	1	
9	<u>102503225</u>	Service Backrest Asm-black	1	
10	<u>102531501</u>	Cover, 4-pass Ns1 Underbody	1	
11	<u>102531701</u>	4-Passenger Rear Seat Bottom, Beige	1	
12	<u>102531702</u>	4-Passenger Rear Seat Bottom, White	1	
13	<u>102531704</u>	4-Passenger Rear Seat Bottom, Gray	1	
14	<u>102541425</u>	Bolt-m6x1.0x25 Hex Flhd, Blk-l	4	
15	<u>102572201</u>	Connector Tube-hand Rail Asm	1	
16	<u>102573101</u>	Bracket, 4-pass Lower Seat	2	
17	<u>102574801</u>	Support-rh 4 Passenger Seat	1	
18	<u>102574901</u>	Support-lh 4 Passenger Seat	1	
19	<u>102575101</u>	Restraint- Rh 4-passenger Hip	1	
20	<u>102575201</u>	Restraint- Lh 4-passenger Hip	1	
Note: See also four-passenger kit information.				

1

G

E



000493-001


REAR FOOTREST ASSEMBLY – PRECEDENT VILLAGER 4

ITEM	PART NO.	DESCRIPTION	QTY	1	G	E
		1 2 3 4				
1	<u>1010434</u>	Barrel - Plastic	10			
2	<u>102298720</u>	M8-1.25x20 Taptite	8			
3	<u>102298745</u>	M8-1.25x45 Taptite	4			
4	<u>102531001</u>	Handrail Weldment, Rear Seat	1			
5	<u>102531402</u>	Footdeck, 4-Passenger, Black	1			
6	<u>102531601</u>	Floormat, 4-Passenger, Rear	1			
7	<u>102534201</u>	Bolt - Fl Hd, M8 X 95	4			
8	<u>102584701</u>	Weld, 4-pass Footdeck-a	1			
9	<u>102584801</u>	Weld, 4-pass Footdeck-b	1			

1

G

E



000505-001


FOUR PASSENGER CONVERSION KIT – BEIGE

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>102570901</u>	Kit-4-pass, Prec, Std, Beige (includes items 2 through 27)	1	
2	<u>1010434</u>	Barrel - Plastic	11	
3	<u>1014902</u>	U-Bolt	2	
4	<u>101705701</u>	Decal, Warning	1	
5	<u>1017235</u>	Bumper, Jounce	2	
6	<u>102296530</u>	Screw - M6 X 1.0 X 30 Sems	4	
7	<u>102298720</u>	M8-1.25x20 Taptite	18	
8	<u>102298745</u>	M8-1.25x45 Taptite	4	
9	<u>102503221</u>	Service Backrest Asm, Beige	1	
10	<u>102531001</u>	Handrail Weldment, Rear Seat	1	
11	<u>102531402</u>	Footdeck, 4-Passenger, Black	1	
12	<u>102531501</u>	Cover, 4-pass Ns1 Underbody	1	
13	<u>102531601</u>	Floormat, 4-Passenger, Rear	1	
14	<u>102531701</u>	4-Passenger Rear Seat Bottom, Beige	1	
15	<u>102534201</u>	Bolt - Fl Hd, M8 X 95	4	
16	<u>102534801</u>	Jounce Bumper Bracket	2	
17	<u>102541425</u>	Bolt-m6x1.0x25 Hex Flhd, Blk-l	6	
18	<u>102544901</u>	Spril, Leaf, Rear	2	
19	<u>102572201</u>	Connector Tube-hand Rail Asm	1	
20	<u>102573101</u>	Bracket, 4-pass Lower Seat	2	
21	<u>102574801</u>	Support-rh 4 Passenger Seat	1	
22	<u>102574901</u>	Support-lh 4 Passenger Seat	1	
23	<u>102575101</u>	Restraint- Rh 4-passenger Hip	1	
24	<u>102575201</u>	Restraint- Lh 4-passenger Hip	1	
25	N/A	Instructions-4 Pass Field	1	
26	<u>102584701</u>	Weld, 4-pass Footdeck-a	1	
27	<u>102584801</u>	Weld, 4-pass Footdeck-b	1	

1

G

E



000505-001

FOUR PASSENGER CONVERSION KIT – WHITE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>102570902</u>	Kit-4-pass, Prec, Std, White (includes items 2 through 27)	1
2	<u>1010434</u>	Barrel - Plastic	11
3	<u>1014902</u>	U-Bolt	2
4	<u>101705701</u>	Decal, Warning	1
5	<u>1017235</u>	Bumper, Jounce	2
6	<u>102296530</u>	Screw - M6 X 1.0 X 30 Sems	4
7	<u>102298720</u>	M8-1.25x20 Taptite	18
8	<u>102298745</u>	M8-1.25x45 Taptite	4
9	<u>102503222</u>	Service Backrest Asm, White	1
10	<u>102531001</u>	Handrail Weldment, Rear Seat	1
11	<u>102531402</u>	Footdeck, 4-Passenger, Black	1
12	<u>102531501</u>	Cover, 4-pass Ns1 Underbody	1
13	<u>102531601</u>	Floormat, 4-Passenger, Rear	1
14	<u>102531702</u>	4-Passenger Rear Seat Bottom, White	1
15	<u>102534201</u>	Bolt - Fl Hd, M8 X 95	4
16	<u>102534801</u>	Jounce Bumper Bracket	2
17	<u>102541425</u>	Bolt-m6x1.0x25 Hex Flhd, Blk-l	6
18	<u>102544901</u>	Spril, Leaf, Rear	2
19	<u>102572201</u>	Connector Tube-hand Rail Asm	1
20	<u>102573101</u>	Bracket, 4-pass Lower Seat	2
21	<u>102574801</u>	Support-rh 4 Passenger Seat	1
22	<u>102574901</u>	Support-lh 4 Passenger Seat	1
23	<u>102575101</u>	Restraint- Rh 4-passenger Hip	1
24	<u>102575201</u>	Restraint- Lh 4-passenger Hip	1
25	N/A	Instructions-4 Pass Field	1
26	<u>102584701</u>	Weld, 4-pass Footdeck-a	1
27	<u>102584801</u>	Weld, 4-pass Footdeck-b	1

1


G

E

1

G

E



000505-001

FOUR PASSENGER CONVERSION KIT – GRAY

ITEM	PART NO.	DESCRIPTION	QTY	1 G E
		1 2 3 4		
1	<u>102570904</u>	Kit, 4 Passenger, Precedent, Std, Gray (includes items 2 through 27)	1	
2	<u>1010434</u>	Barrel - Plastic	11	
3	<u>1014902</u>	U-Bolt	2	
4	<u>101705701</u>	Decal, Warning	1	
5	<u>1017235</u>	Bumper, Jounce	2	
6	<u>102296530</u>	Screw - M6 X 1.0 X 30 Sems	4	
7	<u>102298720</u>	M8-1.25x20 Taptite	18	
8	<u>102298745</u>	M8-1.25x45 Taptite	4	
9	<u>102503224</u>	Service Backrest Asm, Gray	1	
10	<u>102531001</u>	Handrail Weldment, Rear Seat	1	
11	<u>102531402</u>	Footdeck, 4-Passenger, Black	1	
12	<u>102531501</u>	Cover, 4-pass Ns1 Underbody	1	
13	<u>102531601</u>	Floormat, 4-Passenger, Rear	1	
14	<u>102531704</u>	4-Passenger Rear Seat Bottom, Gray	1	
15	<u>102534201</u>	Bolt - Fl Hd, M8 X 95	4	
16	<u>102534801</u>	Jounce Bumper Bracket	2	
17	<u>102541425</u>	Bolt-m6x1.0x25 Hex Flhd, Blk-l	6	
18	<u>102544901</u>	Spril, Leaf, Rear	2	
19	<u>102572201</u>	Connector Tube-hand Rail Asm	1	
20	<u>102573101</u>	Bracket, 4-pass Lower Seat	2	
21	<u>102574801</u>	Support-rh 4 Passenger Seat	1	
22	<u>102574901</u>	Support-lh 4 Passenger Seat	1	
23	<u>102575101</u>	Restraint- Rh 4-passenger Hip	1	
24	<u>102575201</u>	Restraint- Lh 4-passenger Hip	1	
25	N/A	Instructions-4 Pass Field	1	
26	<u>102584701</u>	Weld, 4-pass Footdeck-a	1	
27	<u>102584801</u>	Weld, 4-pass Footdeck-b	1	

1

G


E

WHEEL AND TIRES

2

G




E



000474-001

WHEELS AND TIRES – PROFESSIONAL

ITEM	PART NO.	DESCRIPTION	QTY	2 G E
		1 2 3 4		
1	<u>1010984</u>	.500-20 Unf Lug Nut	16	
2	<u>102522604</u>	Asm-duro Std Gray (includes items 3 through 5)	4	
3	<u>102557801</u>	Wheel Rim Asm, 8" X 7.000"	1	
4	<u>102569304</u>	Duro 18 X 8.5 X 8, 4-Ply	1	
5	<u>7310</u>	Valve Stem	1	
6	<u>102522605</u>	Asm-duro Extra Tract Gray (includes items 7 through 9)	4	
7	N/A	Tire, Unmounted Xtrac 18 x 8.50-8	1	
8	<u>102557801</u>	Wheel Rim Asm, 8" X 7.000"	1	
9	<u>7310</u>	Valve Stem	1	
10	<u>102522608</u>	Asm-carlisle Std Gray (includes items 11 through 13)	2	
11	<u>102557801</u>	Wheel Rim Asm, 8" X 7.000"	1	
12	<u>7310</u>	Valve Stem	1	
13	N/A	Tire, Unmouonted, Carlisle Standard Tread	1	
14	<u>102522609</u>	Asm-carlisle Retail (includes items 15 through 17)	2	
15	<u>102557801</u>	Wheel Rim Asm, 8" X 7.000"	1	
16	<u>102569309</u>	Tire-carlisle 18.5x8.5r8 4-ply	1	
17	<u>7310</u>	Valve Stem	1	



000475-001

WHEELS AND TIRES – CHAMPION

ITEM	PART NO.	DESCRIPTION	QTY	2 G E
		1 2 3 4		
1	<u>102522608</u>	Asm-carlisle Std Gray (includes items 2 through 4)	4	
2	<u>102557801</u>	Wheel Rim Asm, 8" X 7.000"	1	
3	<u>7310</u>	Valve Stem	1	
4	N/A	Tire, Unmouonted, Carlisle Standard Tread	1	
5	<u>102522609</u>	Asm-carlisle Retail (includes items 6 through 8)	4	
6	<u>102557801</u>	Wheel Rim Asm, 8" X 7.000"	1	
7	<u>102569309</u>	Tire-carlisle 18.5x8.5r8 4-ply	1	
8	<u>7310</u>	Valve Stem	1	
9	<u>102540601</u>	Tire and Wheel, Aluminum (includes items 10 through 12)	4	
10	<u>102556701</u>	Tire, Pro Tour, 205-50 X 10	1	
11	<u>102556801</u>	Wheel, ChampionsAluminum'.....	1	
12	<u>7310</u>	Valve Stem	1	
13	<u>102540701</u>	Lug Nut, 1/2" Closed End	16	

2

G

E


DECALS

3

G

E

OFF ON



OPERATING INSTRUCTIONS

- Read owner's manual and safety warnings located on dash panel prior to driving.
- Study and understand controls.

TO OPERATE

- Turn wheels to desired direction and ensure path is clear.
- Turn key to ON position.
- While stopped, place shift lever in desired position:
F – Forward N – Neutral R – Reverse (Buzzer will sound)
- Park brake will release and vehicle will start moving when accelerator pedal is pressed.
- Slowly press accelerator pedal to increase speed.
- To stop, release accelerator pedal and press brake pedal.

BEFORE LEAVING

- Press park brake pedal until it locks and holds vehicle.
- Place Forward/Reverse switch in NEUTRAL position.
- Turn key OFF and remove key when not in use.

CCI 102519201

WARNING

ROLLOVER OR FALLING OFF MAY CAUSE SERIOUS INJURY OR DEATH.

- Before using vehicle, read operating instructions.
- Do not start vehicle until all occupants are seated.
- Keep entire body inside vehicle while moving.
- Drive slowly in turns and straight up and down slopes.
- Use brakes to reduce speed when coasting downhill.
- Never operate under the influence of alcohol or drugs.
- For use by authorized persons in designated areas only.
- Remain seated while moving.
- Operate from driver side only.
- Never operate on public roads.
- Hold on to seat handle while moving.
- Two (2) persons per seat maximum.
- Never stand in front of or behind vehicle.
- Do not leave children unattended on vehicle.

CCI 102519301

WARNING

BATTERY EXPLOSION / FIRE CAN CAUSE SEVERE INJURY

- Do not contact positive (+) battery post or cable to frame.
- Disconnect negative (-) cable first.
- Negative (-) frame ground.

CCI 102517901

WARNING



CAN CAUSE SEVERE INJURY

Rotating parts

HOT manifold & muffler

KEEP CLEAR

CCI 101960501



WARNING

GASOLINE EXPLOSION / FIRE CAN CAUSE SEVERE INJURY OR DEATH

- No sparks or open flame near fuel or fuel tank.
- No smoking near fuel or fuel tank.
- Stop engine and allow to cool before refueling.
- Turn fuel valve () on during operation.
- Turn fuel valve () off during storage or transport.

EXCESSIVE SPEED CAN CAUSE SEVERE INJURY OR DEATH

- Do not tamper with engine governor adjustment.

CCI 102517801


CE

000444-001

DECALS – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	3 G E
		1 2 3 4		
1	<u>101825101</u>	Decal, Off/On	1	
2	<u>101960501</u>	Decal, Rotating Parts/Hot Manifold	2	
3	<u>102517801</u>	Decal, Warning - Gas and Govenor	1	
4	<u>102517901</u>	Decal, Warning - Frame Ground	1	
5	<u>102519201</u>	Decal, Operating Instr, Gas	1	
6	<u>102519301</u>	Decal, Warning, Rollover	1	
7	<u>102538101</u>	Decal, Operating Instructions	1	
8	<u>102540901</u>	Decal, Club Car Clip	1	
Note: Item 7 not shown.				

OFF ON

**IMPORTANT NOTICE**

This vehicle does not conform to ANSI Z130.1 - "Standard for Golf Cars - Safety and Performance Requirements" because it is capable of speeds in excess of 15 miles per hour. Exercise caution.

CC1 10255901

OPERATING INSTRUCTIONS

- Read owner's manual and dash-mounted safety warnings prior to driving.
- Study and understand controls.

TO OPERATE

- Turn wheels to desired direction and ensure path is clear.
- Turn key to ON position.
- While stopped, place Forward/Reverse switch in desired position: F - Forward N - Neutral R - Reverse (Buzzer will sound)
- Park brake will release and vehicle will start moving when accelerator pedal is pressed.
- Slowly press accelerator pedal to increase speed.
- To stop, release accelerator pedal and press brake pedal.

BEFORE LEAVING

- Press park brake pedal until it locks and holds vehicle.
- Place Forward/Reverse switch in NEUTRAL position.
- Turn key OFF and remove key when not in use.

MOTOR BRAKING

- Electric motor braking provides speed regulation functions.
- For parked vehicle, beeping alarm indicates vehicle roll away.
- In operation, beeping alarm indicates reduction in motor braking.
- Apply brakes to further reduce vehicle speed as required.
- System is activated only when tow switch is in the RUN position.
- When towing this vehicle, tow switch must be in the TOW position.

CC1 102518001

WARNING**ROLLOVER OR FALLING OFF MAY CAUSE SERIOUS INJURY OR DEATH.**

- Before using vehicle, read operating instructions.
- Do not start vehicle until all occupants are seated.
- Keep entire body inside vehicle while moving.
- Drive slowly in turns and straight up and down slopes.
- Use brakes to reduce speed when coasting downhill.
- Never operate under the influence of alcohol or drugs.
- For use by authorized persons in designated areas only.
- Remain seated while moving.
- Operate from driver side only.
- Never operate on public roads.
- Hold on to seat handle while moving.
- Two (2) persons per seat maximum.
- Never stand in front of or behind vehicle.
- Do not leave children unattended on vehicle.

CC1 102519301

WARNING**HEAVY LIFTING CAN CAUSE SEVERE PERSONAL INJURY**


- The weight of each 12-volt battery is in excess of 80 lb (36.3 kg).
- Lift batteries only with the aid of an assistant.

CC1 1023238501

CAUTION**EXPOSURE TO WATER MAY DAMAGE ELECTRONIC COMPONENTS**

- Do not operate vehicle without this cover properly installed.
- Do not direct water stream in the area of the cover without cover securely in place.
- See vehicle maintenance and service manual before servicing.

CC1 102518101

**WARNING****BATTERY EXPLOSION / ELECTRICAL COMPONENT DAMAGE**

- Place Run/Tow switch in TOW position before performing any of the following:
 - Disconnecting or connecting battery cables
 - Towing this vehicle
 - Extended storage
 - Servicing the vehicle
- Do not store items in battery compartment.
- Do not operate vehicle without the cover properly installed.
- Keep electronic components dry.
- See vehicle maintenance and service manual before servicing.

CC1 102519401

WARNING**SHORTING OF BATTERY TERMINALS CAN CAUSE PERSONAL INJURY OR DEATH.**


- Do not place component mounting plate directly on top of batteries, when removing or installing plate.
- Remove plate from vehicle completely.

102527501

000441-001

DECALS – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	3 G E
		1 2 3 4		
1	<u>101825101</u>	Decal, Off/On	1	
2	<u>102518001</u>	Decal, Operating Instr, Elec	1	
3	<u>102518101</u>	Decal, Run/Tow with Storage Area	1	
4	<u>102518301</u>	Decal, Caution, Electrical Component Cover	1	
5	<u>102519301</u>	Decal, Warning, Rollover	1	
6	<u>102519401</u>	Decal, Run/Tow Safety, IQ	1	
7	<u>102527501</u>	Decal-component Mounting Plate	1	
8	<u>102538201</u>	Decal, Operating Instructions	1	
9	<u>102540901</u>	Decal, Club Car Clip	1	
10	<u>102555901</u>	Decal, Private Speed, Prec	1	
11	<u>103238501</u>	Decal, Warning -battery Weight	1	
Note: Item 8 not shown.				

3**G****E**

 WARNING

**FALLING OFF COULD RESULT
IN SEVERE INJURY OR DEATH**

- Remain seated with entire body inside vehicle and hold on to seat handle or handrail at all times.
- Two (2) persons per bench seat maximum.
- One (1) person per bucket seat maximum.
- Do not leave children unattended on vehicle at anytime.
- Never stand in front of or behind vehicle.

CCI 101705701



000495-001

DECAL – PRECEDENT VILLAGER 4

ITEM	PART NO.	DESCRIPTION	QTY	3 G E
1	<u>101705701</u>	1 2 3 4 Decal, Warning	4	

3

G


E

BRAKES AND PEDAL GROUP ASSEMBLIES

4

G


E

4**G****E**

000186-001

REAR BRAKE ASSEMBLY, SELF-ADJUSTING

ITEM	PART NO.	DESCRIPTION	QTY	4 G E
		1 2 3 4		
1	<u>1013924</u>	Nut, 5/16-24 Hex Head Cone	8	
2	<u>1014153</u>	Bolt, Brake Cluster Mounting	8	
3	<u>101791101</u>	Drum without Center Hole, Brake	2	
4	<u>103380201</u>	Asm, Brake Cluster, Mech, Drvr (includes items 5 through 17)	1	
5	<u>101815501</u>	Lever Assembly, Self-Adjusting Brake, Right (Passenger)	1	
6	<u>101816501</u>	Adj Mechanism, S.A. Brakes, Right (Passenger)	1	
7	<u>101823201</u>	Package, Brake Shoe, Self-Adjusting	1	
8	<u>101823801</u>	Plate, Washer, Brake, Self-Adjusting	1	
9	<u>103483101</u>	Back Plate, Rh	1	
10	<u>103483201</u>	Kit, Shoe Retainer (includes items 11 and 12)	1	
11	<u>1010953</u>	Pin	2	
12	<u>103483301</u>	Spring, Shoe, Clamp	2	
13	<u>103483401</u>	Package Brake Spring Self Adj (includes items 14 and 15)	1	
14	<u>101816401</u>	Brake Spring Self Adj	2	
15	<u>103483501</u>	Spring Brake	2	
16	<u>103483601</u>	Cover, Dust	1	
17	<u>103483701</u>	Brake Block	1	
18	<u>103380202</u>	Asm, Brake Cluster, Mech, Pass (includes items 19 through 31)	1	
19	<u>101815502</u>	Lever Assembly, Self-Adjusting Brake, Left	1	
20	<u>101816502</u>	Adjusting Mechanism, Self-Adjusting Brake, Left	1	
21	<u>101823201</u>	Package, Brake Shoe, Self-Adjusting	1	
22	<u>101823801</u>	Plate, Washer, Brake, Self-Adjusting	1	
23	<u>103483102</u>	Back Plate, Lh	1	
24	<u>103483201</u>	Kit, Shoe Retainer (includes items 25 and 26)	1	
25	<u>1010953</u>	Pin	2	
26	<u>103483301</u>	Spring, Shoe, Clamp	2	
27	<u>103483401</u>	Package Brake Spring Self Adj (includes items 28 and 29)	1	
28	<u>101816401</u>	Brake Spring Self Adj	2	
29	<u>103483501</u>	Spring Brake	2	
30	<u>103483601</u>	Cover, Dust	1	
31	<u>103483701</u>	Brake Block	1	
Note: Driver-side brake cluster not shown. Components have a similar appearance to passenger-side brake cluster components.				



000467-001


BRAKE CABLES

ITEM	PART NO.	DESCRIPTION	QTY	4
		1 2 3 4		G
1	N/A	Kit, Brake Cable, Prec Upgrade (includes items 2 through 11)	1	E
2	<u>103528701</u>	Kit, Brake Cable, Prec, Rh (includes items 3 through 5)	1	
3	<u>1010829</u>	Pin, Clevis, 5/16 X 3/4	1	
4	<u>102292801</u>	Pin, Bow Tie Locking - .072	1	
5	103528501	Cable, Brake, Prec, Right	1	
6	<u>103528702</u>	Kit, Brake Cable, Prec, Lh (includes items 7 through 9)	1	
7	<u>1010829</u>	Pin, Clevis, 5/16 X 3/4	1	
8	<u>102292801</u>	Pin, Bow Tie Locking - .072	1	
9	103528601	Cable, Brake, Prec, Left	1	
10	<u>103535001</u>	Bracket, Equalizer, Prec Awd	1	
11	N/A	Instr, Prec Brake Cable Kit	1	

4

G

E



000443-001


PEDAL GROUP CONNECTIONS – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	4 G E
		1 2 3 4		
1	<u>1010434</u>	Barrel - Plastic	1	
2	<u>102292201</u>	Screw-1/4-20x2.20 Tx Pn Hd Sd	2	
3	<u>102297901</u>	Bolt, 5/16-18 X 7.375, Hex	1	
4	<u>102298030</u>	Screw, K80x30, Torx Pn Hd Pt	2	
5	<u>102500801</u>	Plate - Floor Cover	1	
6	<u>102513102</u>	Cable, Acc, Snap-in	1	
7	<u>102551901</u>	Washer, 5/16, Self Comp, Cup	1	
8	<u>102552001</u>	Washer, 5/16, Self Comp, Cone	1	
9	<u>102594301</u>	Nut, 5/16-18, Hex Adjusting -I	1	
10	<u>103535001</u>	Bracket, Equalizer, Prec Awd	1	
11	<u>1242</u>	Nut, 5/16-18 Hex	1	

4

G

E



000442-001


PEDAL GROUP CONNECTIONS – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	4
		1 2 3 4		G
1	<u>1010434</u>	Barrel - Plastic	1	E
2	<u>102292201</u>	Screw-1/4-20x2.20 Tx Pn Hd Sd	2	
3	<u>102297901</u>	Bolt, 5/16-18 X 7.375, Hex	1	
4	<u>102298030</u>	Screw, K80x30, Torx Pn Hd Pt	2	
5	<u>102500801</u>	Plate - Floor Cover	1	
6	<u>102551901</u>	Washer, 5/16, Self Comp, Cup	1	
7	<u>102552001</u>	Washer, 5/16, Self Comp, Cone	1	
8	<u>102594301</u>	Nut, 5/16-18, Hex Adjusting -I	1	
9	<u>103535001</u>	Bracket, Equalizer, Prec Awd	1	
10	<u>103744901</u>	Adapter, Gen 2 Pedal, Mcor	1	
11	<u>103745001</u>	Drive Bar, Gen 2 Pedal, Mcor	1	
12	<u>1242</u>	Nut, 5/16-18 Hex	1	

4

G

E



000487-001


PEDAL GROUP COMPONENTS – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	4 G E
		1 2 3 4		
1	<u>102500101</u>	Asm, Pedal Box Gas (includes items 2 through 17)	1	
2	<u>102558801</u>	Shield, Debris	1	
3	<u>102558901</u>	Pad, Pedal, Accelerator	1	
4	<u>102559001</u>	Pad, Pedal, Park	1	
5	<u>102559101</u>	Pad, Pedal, Brake	1	
6	<u>102559301</u>	Spring, Brake, Return	1	
7	<u>102559401</u>	Rod, Brake	1	
8	<u>102559601</u>	Shield, Debris, Aux	1	
9	<u>102559701</u>	Nut, Brake Rod	1	
10	<u>102563001</u>	Washer, Std Fender, #10	3	
11	<u>102563101</u>	Screw, Type A, #10	5	
12	<u>102587401</u>	Assembly Pawl Lock Headed Pins (includes items 13 and 14)	1	
13	<u>102587501</u>	Clip, Push, Pawl	2	
14	<u>103344301</u>	Spring, Pawl Return	1	
15	<u>102588701</u>	Kit, Pedal Spring	1	
16	<u>102588901</u>	Clip, U	1	
17	<u>103327701</u>	Kit, Gcor (includes items 18 and 19)	1	
18	<u>102528601</u>	GCOR, Prec	1	
19	N/A	Instr, Kit Gcor/mcor	1	
Note: Replace pedal box assembly with Generation 2 pedal box assembly (CCI P/N 102595021). Generation 2 pedal box assembly will also require new accelerator pedal cable (CCI P/N 102595101).				

4

G

E



000488-001

PEDAL GROUP COMPONENTS – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	4
		1 2 3 4		G
1	<u>102500001</u>	Asm, Pedal Box Elec (includes items 2 through 17)	1	E
2	<u>102558801</u>	Shield, Debris	1	
3	<u>102558901</u>	Pad, Pedal, Accelerator	1	
4	<u>102559001</u>	Pad, Pedal, Park	1	
5	<u>102559101</u>	Pad, Pedal, Brake	1	
6	<u>102559301</u>	Spring, Brake, Return	1	
7	<u>102559401</u>	Rod, Brake	1	
8	<u>102559601</u>	Shield, Debris, Aux	1	
9	<u>102559701</u>	Nut, Brake Rod	1	
10	<u>102563001</u>	Washer, Std Fender, #10	3	
11	<u>102563101</u>	Screw, Type A, #10	5	
12	<u>102587401</u>	Assembly Pawl Lock Headed Pins (includes items 13 and 14)	1	
13	<u>102587501</u>	Clip, Push, Pawl	2	
14	<u>103344301</u>	Spring, Pawl Return	1	
15	<u>102588701</u>	Kit, Pedal Spring	1	
16	<u>102588901</u>	Clip, U	1	
17	<u>103327901</u>	Kit, Mcor (includes items 18 and 19)	1	
18	<u>102528501</u>	Mcor, Prec	1	
19	N/A	Instr, Kit Gcor/mcor	1	
Note: Replace pedal box assembly with Generation 2 pedal box assembly (CCI P/N 102595012).				


4
G
E

STEERING, FRONT AND REAR SUSPENSION

5

G

E



000470-002


STEERING WHEEL – CHAMPION

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>103796701</u>	Kit, Hex, Steering Wheel (includes items 2 through 15)	1	
2	<u>1016663</u>	Screw, #12-14 X 0.625	2	
3	<u>102290120</u>	Bolt, M10 X 20 Hex Washer Hd	1	
4	<u>103724503</u>	Steering Wheel, Soft Hex	1	
5	<u>103724901</u>	Asm, Scorecard, Clip (includes items 6 through 10)	1	
6	<u>1012565</u>	Screw, #12 Phillips Round Head	2	
7	<u>1012566</u>	Tapered Compression Spring	2	
8	<u>1016154</u>	Clip, Scorecard	1	
9	N/A	Pencil Grip	1	
10	<u>103724601</u>	Cover, Steering Wheel, Clip	1	
11	N/A	Decal, Op Instr, Ele	1	
12	<u>103783002</u>	Decal, Op Instr, Gas Ps	1	
13	<u>103783003</u>	Decal, Op Instr, Gas Ks	1	
14	<u>103783004</u>	Decal, Op Instr, Limo Ab	1	
15	<u>103797301</u>	Kit Instr, Steering Wheel	1	

5

G

E



000471-001


STEERING WHEEL – PROFESSIONAL

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>101615602</u>	Wheel Assy, Tri-Lobe Steering	1	
2	1016219	Plate, Scorecard (includes items 3 through 7)	1	
3	<u>1012565</u>	Screw, #12 Phillips Round Head	2	
4	<u>1012566</u>	Tapered Compression Spring	2	
5	1016154	Clip, Scorecard	1	
6	N/A	Plate, Score Card	1	
7	N/A	Pencil Grip	1	
8	<u>1016663</u>	Screw, #12-14 X 0.625	2	

5

G

E



000469-002


STEERING COLUMN

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	102290120	Bolt, M10 X 20 Hex Washer Hd	1	
2	<u>102298116</u>	Bolt - Flanged Hd, M8 X 16.0	4	
3	<u>102298130</u>	Bolt, Flange Head, M8 X 30.0	2	
4	<u>103209501</u>	Assy, Steering Column, Ld	1	
5	<u>103810201</u>	Kit, Prec Lower Yoke, Wanda	1	

5

G

E



000469-001


STEERING COLUMN – ELECTRIC VEHICLES

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	102290120	Bolt, M10 X 20 Hex Washer Hd	1	
2	<u>102298116</u>	Bolt - Flanged Hd, M8 X 16.0	4	
3	<u>102298130</u>	Bolt, Flange Head, M8 X 30.0	2	
4	<u>102507101</u>	Steering Column Assembly	1	

5

G


E



000476-001

STEERING GEAR ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>102022601</u>	End, Tie Rod M12 X 1.25 Rh	2	
2	<u>102288601</u>	Steering Gear Box Assembly (includes items 3 through 21)	1	
3	<u>102564901</u>	Asm, Pinion, Steer Gear, Prec (includes items 4 through 6)	1	
4	N/A	Pinion, Steering	1	
5	N/A	Bearing, Ball	1	
6	N/A	Ring, Retaining	1	
7	<u>102565101</u>	Ring, C-type, Stop, Prec	1	
8	<u>102565201</u>	Seal, Dust, Steering, Pinion	1	
9	<u>102565301</u>	Yoke, Support	1	
10	<u>102565401</u>	Spring, Yoke, Prec	1	
11	<u>102565701</u>	Assy, Ball Joint, Inner, Prec	2	
12	<u>102565801</u>	Wrap, Tie, Steel, Prec	2	
13	<u>102565901</u>	Bellows, Steering	2	
14	<u>102566001</u>	Clip, Steering, Prec	2	
15	<u>102566101</u>	Nut,m12-1.25,jam,steer,prec	2	
16	N/A	Housing, Pinion (includes items 17 and 18)	1	
17	N/A	Bearing, Needle	1	
18	N/A	Bushing, Rack	1	
19	N/A	Plug, Yoke	1	
20	N/A	Nut, Lock, Rack Screw	1	
21	N/A	Rack, Steering	1	
22	<u>102289001</u>	Screw, M8X1.25X30, Hex	3	
23	<u>102289201</u>	Nut - Hex Locking, M12 X 1.25	2	
24	<u>102289301</u>	Rue Ring - 1/2"	2	

5**G****E**

000445-001


FRONT SUSPENSION, UPPER

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>102287101</u>	Assembly - Front Structure	1	
2	<u>102288901</u>	Bolt - Hex, M8x1.25 X 135	2	
3	<u>102289401</u>	Screw- Hex Cap, M8 X 1.25 X 45	4	
4	<u>102289501</u>	Screw- Hex Cap, M8 X 1.25 X 70	2	
5	<u>102289601</u>	Upper Clevis Assembly - Rh	1	
6	<u>102289701</u>	Upper Clevis Assembly - Lh	1	
7	<u>102289901</u>	Kit, Susp, Bushing Joints (includes items 8 through 11)	1	
8	<u>102287601</u>	Sleeve - Rolled, Outer	2	
9	<u>102287701</u>	Sleeve - Rolled, Inner	2	
10	<u>102288101</u>	Sleeve - Rolled, Spring	2	
11	<u>102956201</u>	Bushing, Urethane, Short, Prec	12	
12	<u>102505701</u>	Assembly, Dash Support	1	
13	<u>102588601</u>	Shock Absorber Front Prv Spd	2	
14	<u>102878201</u>	Nut, Lock,m12,washer,conical	2	
15	<u>103388501</u>	Asm, 3 Piece A-arm, Bushings	2	
Note: Item 15 includes bushings and sleeves. Item 7 (not shown) includes bushings and sleeves for control arms, and front suspension leaf spring. See lower suspension page for illustration of item 10.				

5

G


E



000477-001

FRONT SUSPENSION, LOWER


ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>102287201</u>	Assembly - King Pin	2	
2	<u>102287901</u>	Knuckle Spindle Asm - Lh	1	
3	<u>102289101</u>	Screw-m10x1.5, Trilob, Hex Fl	4	
4	<u>102289201</u>	Nut - Hex Locking, M12 X 1.25	2	
5	<u>102289301</u>	Rue Ring - 1/2"	2	
6	<u>102289501</u>	Screw- Hex Cap, M8 X 1.25 X 70	2	
7	<u>102289801</u>	Clamp - Leaf Spring	1	
8	N/A	Replacement Kit, Front Hub (includes items 9 through 11)	1	
9	<u>102353201</u>	Cap, Front Hub	1	
10	<u>102353301</u>	Hex Nut, Locking Flange, M14x2	1	
11	N/A	Asm, Front Hub, Bb, Long Stud (includes items 12 through 15)	1	
12	N/A	Bearing, Ball, 6204	2	
13	N/A	Spacer, Bearing, Front Hub, Pm	1	
14	<u>103477901</u>	Lug Stud, 1/2-20 Unf, 4037	4	
15	N/A	Front Hub, Ball Brg, Long Stud	1	
16	<u>102878101</u>	Assy, Knuckle, Right Side (includes items 17 and 18)	1	
17	N/A	Bushings, Knuckle Spindle Asym	2	
18	N/A	Fitting, Grease, Knuckle Spindle Asym	1	
19	<u>102973801</u>	Kit, Susp, Kingpin Joints (includes items 20 through 23)	1	
20	<u>102287201</u>	Assembly - King Pin	2	
21	<u>102288201</u>	Bushing - Flanged	4	
22	<u>102288401</u>	Wave Washer - Kingpin	2	
23	<u>102878201</u>	Nut, Lock,m12,washer,conical	2	
24	<u>103711001</u>	Asm, Spring, Leaf, Front, Prec (includes items 25 through 27)	1	
25	<u>102288101</u>	Sleeve - Rolled, Spring	2	
26	<u>102956201</u>	Bushing, Urethane, Short, Prec	4	
27	N/A	Spring, 1 Leaf, Front	1	
28	<u>706</u>	Nut, Hex 3/8-16	1	
29	<u>8745</u>	Screw, Eccentric Adjustment	1	
Note: Note: Item 15 not used in all applications.				



000446-001

REAR SUSPENSION – GASOLINE VEHICLE


ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>1010145</u>	Nut, 3/8-24 Hex	4	
2	<u>1011415</u>	Kit, Shock Absorber Cushion (includes items 3 and 4)	2	
3	<u>1010142</u>	Cushion, Shock Absorber	2	
4	<u>1010144</u>	Retainer, Shock Absorber Cushion	2	
5	<u>1012180</u>	U-Bolt	2	
6	<u>1012181</u>	Bracket, Shock Mounting, Right (Passenger)	1	
7	<u>1012182</u>	Bracket, Shock Mounting, Left (Driver)	1	
8	<u>1014555</u>	Locknut, 7/16-14 Nylon Hex	4	
9	<u>102298170</u>	Bolt - Flange Hd, M8 X 70.0	2	
10	<u>102298185</u>	Bolt - Flange Hd, M8 X 85.0	4	
11	<u>102298401</u>	Nut,m8,all Metal Lock	6	
12	<u>102506201</u>	Shackle - Rear	2	
13	<u>102506301</u>	Sleeve - Shackle Upper	2	
14	<u>102506401</u>	Sleeve - Spring Eye Mounts	4	
15	<u>102506601</u>	Bushing - Urethane	12	
16	<u>102513001</u>	Rear Leaf Spring, Gas	2	
17	<u>102588501</u>	Shock Absorber Rear Prv Spd	2	



000446-001

REAR SUSPENSION – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>1010145</u>	Nut, 3/8-24 Hex	4	
2	<u>1011415</u>	Kit, Shock Absorber Cushion (includes items 3 and 4)	2	
3	<u>1010142</u>	Cushion, Shock Absorber	2	
4	<u>1010144</u>	Retainer, Shock Absorber Cushion	2	
5	<u>1012180</u>	U-Bolt	2	
6	<u>1012181</u>	Bracket, Shock Mounting, Right (Passenger)	1	
7	<u>1012182</u>	Bracket, Shock Mounting, Left (Driver)	1	
8	<u>1014555</u>	Locknut, 7/16-14 Nylon Hex	4	
9	<u>102298170</u>	Bolt - Flange Hd, M8 X 70.0	2	
10	<u>102298185</u>	Bolt - Flange Hd, M8 X 85.0	4	
11	<u>102298401</u>	Nut,m8,all Metal Lock	6	
12	<u>102506201</u>	Shackle - Rear	2	
13	<u>102506301</u>	Sleeve - Shackle Upper	2	
14	<u>102506401</u>	Sleeve - Spring Eye Mounts	4	
15	<u>102506601</u>	Bushing - Urethane	12	
16	<u>102509301</u>	Rear Leaf Spring, Elec	2	
17	<u>102588501</u>	Shock Absorber Rear Prv Spd	2	



000492-001

REAR SUSPENSION – PRECEDENT VILLAGER 4

ITEM	PART NO.	DESCRIPTION	QTY	5 G E
		1 2 3 4		
1	<u>1010145</u>	Nut, 3/8-24 Hex	4	
2	<u>1011415</u>	Kit, Shock Absorber Cushion (includes items 3 and 4)	2	
3	<u>1010142</u>	Cushion, Shock Absorber	2	
4	<u>1010144</u>	Retainer, Shock Absorber Cushion	2	
5	<u>1012181</u>	Bracket, Shock Mounting, Right (Passenger)	1	
6	<u>1012182</u>	Bracket, Shock Mounting, Left (Driver)	1	
7	<u>1014555</u>	Locknut, 7/16-14 Nylon Hex	4	
8	<u>1014902</u>	U-Bolt	2	
9	<u>1017235</u>	Bumper, Jounce	2	
10	<u>102298170</u>	Bolt - Flange Hd, M8 X 70.0	2	
11	<u>102298185</u>	Bolt - Flange Hd, M8 X 85.0	4	
12	<u>102298401</u>	Nut,m8,all Metal Lock	6	
13	<u>102506201</u>	Shackle - Rear	2	
14	<u>102506301</u>	Sleeve - Shackle Upper	2	
15	<u>102506401</u>	Sleeve - Spring Eye Mounts	4	
16	<u>102506601</u>	Bushing - Urethane	12	
17	<u>102534801</u>	Jounce Bumper Bracket	2	
18	<u>102544901</u>	Spril, Leaf, Rear	2	
19	<u>102588501</u>	Shock Absorber Rear Prv Spd	2	

5


G

E

ELECTRICAL SYSTEM – GASOLINE VEHICLE

6

G




000490-002

ELECTRICAL COMPONENTS, FRONT BODY – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1012505</u>	Keys (set of 2)	1
2	<u>1016630</u>	Light, Oil	1
3	<u>1016849</u>	Screw, #4-24 X 0.33 Pan-Head Machine	2
4	<u>1016851</u>	Buzzer, Reverse (9-48 VDC)	1
5	<u>101830701</u>	Nut, Key Switch	1
6	<u>101834502</u>	Cap, Black Key Switch	1
7	<u>101851101</u>	Washer, Key Switch	1
8	<u>102515001</u>	Ip Control Harness, Gas (includes item 9)	1
9	N/A	Connector, Plug 9-pin	1
10	<u>102515101</u>	Key Switch, Gas, Prec	1
11	<u>102522901</u>	Instrument Panel (standard)	1
12	<u>102536601</u>	Instrument Panel (with Hole for Headlight Switch)	1
13	<u>102536602</u>	Instrument Panel (with Hole for Fuel Gauge)	1
14	<u>102536604</u>	Instrument Panel (with Hole for Headlight Switch and Fuel Gauge)	1
15	<u>AM10079</u>	Bulk Std Keys (50) *	1
		 * Note: Must order in multiples of 50.	

6


G




000479-001

BATTERY – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY	6
		1 2 3 4		G
1	<u>1012295</u>	Fuse, 10-Amp	1	
2	<u>1013609</u>	Solenoid, 12-Volt	1	
3	<u>1014375</u>	Screw, 3/8-16 X 0.50 Stainless Steel Hex-Head	2	
4	<u>101898001</u>	Clamp, Battery	1	
5	N/A	Cover, Fuse, Sealed, Metri	1	
6	<u>102296020</u>	Screw, Torx Pan Hd Pt, M6 X 20	4	
7	<u>102296040</u>	Screw, Torx Pan Hd Pt, M6 X 40	1	
8	<u>102355301</u>	Lockwasher, #10 Split Ss	2	
9	<u>102803301</u>	Asm, Voltage Regulator, Prec.	1	
10	N/A	Battery, Start, 12v	1	
11	<u>1242</u>	Nut, 5/16-18 Hex	2	
12	<u>7893</u>	Nut, #10-32 Hex	2	



000481-001




See previous two pages for illustration.

WIRING – GASOLINE VEHICLE


ITEM	PART NO.	DESCRIPTION	QTY
1	<u>102586201</u>	1 2 3 4 Main Harness, Gas	1

6

G



000489-001



000489-001


See previous two pages for illustration.

INSTRUMENT PANEL WIRE HARNESS

ITEM	PART NO.	DESCRIPTION	QTY
1	<u>102515001</u>	1 2 3 4 Ip Control Harness, Gas (includes item 2)	1
2	N/A	Connector, Plug 9-pin	1

6

G




000124-001

STARTER/GENERATOR ASSEMBLY MODEL G425419 – GASOLINE VEHICLES

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101833701</u>	Starter/Generator (cw) (includes items 2 through 33)	1
2	<u>1013001</u>	Bearing, Output Shaft Ball	1
3	<u>1013003</u>	Key, Starter/Generator	1
4	<u>1013005</u>	Bearing, Ball	1
5	<u>101301102</u>	Brush Holder Assembly (cw) (includes item 6)	1
6	<u>101878101</u>	Brush Spring Set	4
7	<u>101869302</u>	Brush and Screw Set (cw)	1
8	<u>101874901</u>	Front Bracket	1
9	<u>101875001</u>	Retainer	1
10	<u>101875101</u>	Armature	1
11	<u>101875201</u>	Field Coil Housing	1
12	<u>101875301</u>	Pole Set	1
13	<u>101875401</u>	Screw Set	1
14	<u>101875501</u>	Field Stator Coil Assembly	1
15	<u>101875601</u>	F Insulator Set	2
16	<u>101875701</u>	DF Insulator	1
17	<u>101875802</u>	A Connector (cw)	1
18	<u>101876001</u>	Screw and Mold Assembly	2
19	<u>101876202</u>	Brush Connector Assembly (cw)	2
20	<u>101876301</u>	Cover Set (includes items 21 and 22)	1
21	<u>1012991</u>	Brush Inspection Port Cover	3
22	<u>1017653</u>	Brush Port Cover w/Drain	1
23	<u>101876402</u>	Rear Bracket (cw)	1
24	<u>101876501</u>	Nut and Screw Set (includes items 25 through 29)	1
25	<u>101896501</u>	Brush Holder Asm Screw	2
26	N/A	Washer, M5 Flat	1
27	N/A	Washer, M14 Lock	1
28	N/A	Nut, Hex, M14 x 2	1
29	N/A	Screw, M5 x 0.8 x 18mm	3
30	<u>101877601</u>	Nut and Washer Set	2
31	<u>101877701</u>	Nut and Washer Set	1
32	<u>101879001</u>	Through Bolt Set	2
33	<u>101939901</u>	Spacer	1
34	<u>101875102</u>	Armature Asm Conversion Kit (includes items 35 through 38)	1
35	<u>1013003</u>	Key, Starter/Generator	1
36	<u>1014289</u>	Pulley, Starter/Generator	1
37	<u>101875101</u>	Armature	1
38	<u>101939901</u>	Spacer	1
		Note: Item 36 will ONLY fit Model G425419 Starter/Generator.	

6

G



000238-004

STARTER/GENERATOR MOUNTING – FE350

ITEM	PART NO.	DESCRIPTION	QTY	6
		1 2 3 4		G
1	<u>1012830</u>	Screw, M8-125 X 22 Hex-Head	2	
2	<u>101524002</u>	Bracket, Starter/Generator Mounting	1	
3	<u>1015932</u>	Bolt, Carriage, 5/16-18	1	
4	<u>1016074</u>	Screw, M8-1.25 X 18mm Torx	1	
5	<u>1016883</u>	Bracket, Starter/Generator Adjustment	1	
6	<u>101837301</u>	Wire Assy, #6 Green	1	
7	<u>101916701</u>	V-Belt	1	
8	<u>1241</u>	Washer, 5/16 Type A Flat	1	
9	<u>1242</u>	Nut, 5/16-18 Hex	1	
10	<u>1624</u>	Screw, 3/8-16 X 1.50 Hex-Head Cap	2	
11	<u>7174</u>	Lockwasher, 5/16 Split	3	
12	<u>8754</u>	Locknut, 3/8-16 Hex	2	



6

G

AS11 FE350 ENGINE

7

G




000201-001

AS11 FE350 ENGINE WITHOUT ACR (AUTOMATIC COMPRESSION RELEASE) – SHROUDS AND BRACKETS

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1015332</u>	Wire Assembly, #10, Uninsulated	1
2	<u>1015649</u>	Shroud, Fan	1
3	<u>1015969</u>	Screw, M6-1.00 X 10mm Pan Hd	4
4	<u>101887601</u>	Locknut, M6-1.00 Nylon Insert	1
5	<u>101953802</u>	Engine, FE350 (cw) without ACR * (includes items 6 through 17)	1
6	<u>1016456</u>	Bolt, Flange Head, M6 x 1 x 12 mm	14
7	<u>1016507</u>	Bolt, Two-Ended	3
8	<u>1016531</u>	Dipstick	1
9	<u>1016539</u>	O-Ring	1
10	<u>1016547</u>	Nut, M6 Flange	3
11	<u>1017474</u>	Shroud, Engine	1
12	<u>1017475</u>	Shroud, Engine	1
13	<u>1017476</u>	Shroud, Engine	1
14	<u>1017486</u>	Tube, Oil Filler	1
15	<u>1017500</u>	Spacer 6.50 X 12 X 5.5	2
16	<u>101916101</u>	Housing, FE350 Fan	1
17	N/A	Washer, 6mm Flat	3
* Note: FE350 engine component listings span several pages.			

7
G




000202-001

AS11 FE350 ENGINE – IGNITION COMPONENTS AND FLYWHEEL

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	1016445	Bracket, RPM Limiter	1
2	<u>1016455</u>	Bolt, Flange Head	2
3	1016456	Bolt, Flange Head, M6 x 1 x 12 mm	2
4	<u>1016497</u>	Screw, Pan WP Cross	1
5	<u>1016544</u>	Screw	1
6	<u>1016561</u>	Clamp	1
7	<u>1016562</u>	Key	1
8	<u>1016578</u>	Ignition, Grommet	1
9	<u>1016579</u>	Band, RPM Limiter Mount	1
10	1016586	Damper, RPM Limiter	1
11	<u>1016587</u>	Clamp	1
12	<u>1016588</u>	Tube, 7mm X 10mm X 70mm	1
13	<u>1017448</u>	Bolt, Flanged	3
14	<u>1017455</u>	Plate, Flywheel Fan	1
15	<u>1017463</u>	Cap Asm Plug	1
16	<u>1017468</u>	Clamp	1
17	<u>1017490</u>	Washer, Flat	1
18	<u>101881101</u>	Spark Plug, OHV (Autolite)	1
19	<u>101909201</u>	Coil, Ignition	1
20	<u>101909301</u>	Lead Wire Assy	1
21	101909401	Limiter, RPM	1
22	101909501	Clamp, Steel	1
23	<u>101916201</u>	Flywheel	1
24	<u>101916301</u>	Fan (cw)	1
25	N/A	Nut, Hex, 18 mm Fine	1
26	<u>AM10724</u>	Spark Plug, OHV (NGK)	1

7


G



000203-001

FE350 ENGINE – OIL CIRCULATION

ITEM	PART NO.	DESCRIPTION	QTY	7
		1 2 3 4		G
1	1016429	Seat, Value Oil Press Relief	1	
2	<u>1016432</u>	Gasket, Drain Plug	1	
3	<u>1016457</u>	Bolt, Flange Head	2	
4	<u>1016467</u>	Filter, Oil	1	
5	<u>1016473</u>	Plate, Oil Pump	1	
6	<u>101648203</u>	Oil Pump And Rotor	1	
7	<u>1016502</u>	Bracket, Oil Filter Mount	1	
8	<u>1016537</u>	Ball, Steel, Press, Relief	1	
9	<u>1016570</u>	O-Ring	1	
10	1016576	Plug, Drain	1	
11	<u>1016581</u>	Spring	1	
12	<u>1017442</u>	Gasket	1	
13	<u>1017456</u>	Bolt, Flanged	6	
14	<u>1017458</u>	Filter	1	
15	<u>1017460</u>	Cover, Pump	1	
16	<u>1017507</u>	Plug	2	




000204-001

AS11 FE350 ENGINE – CYLINDER HEAD

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1016436</u>	Gasket, Rocker Case	1
2	<u>1016449</u>	Retainer, Valve Spring	2
3	<u>1016450</u>	Collet	4
4	<u>1016452</u>	Shaft, Rocker	1
5	<u>1016458</u>	Bolt, Flange Head, M8 x 1.25 x 45 mm	6
6	<u>1016474</u>	Plate	1
7	<u>1016479</u>	Seat, Spring	2
8	<u>1016483</u>	Valve	1
9	<u>1016489</u>	Stud, Two-Ended, M8-1.25	2
10	<u>1016517</u>	Circlip, Type-E	1
11	<u>1016544</u>	Screw	1
12	<u>1016549</u>	Washer, 12.1x19x1.8	1
13	<u>1016563</u>	Pin	2
14	<u>1016566</u>	Seal, Oil	2
15	<u>1016569</u>	O-Ring	2
16	<u>1016583</u>	Bolt, 6x35	2
17	<u>1017434</u>	Gasket, Head	1
18	<u>1017435</u>	Assembly, Cylinder Head, FE350 (includes items 19 through 21)	1
19	<u>1016518</u>	Guide, Valve, Exhaust	1
20	<u>1016519</u>	Guide, Valve	1
21	<u>1016560</u>	Snap Ring	2
22	<u>1017444</u>	Valve, Intake	1
23	<u>1017445</u>	Valve, Exhaust	1
24	<u>1017446</u>	Arm, Rocker	2
25	<u>1017454</u>	Rod, Push	2
26	<u>1017473</u>	Spring, Engine Valve	2
27	<u>102304801</u>	Kit, Gasket, FE350 (includes items 28 through 31)	1
28	<u>1016440</u>	Gasket, Engine to Insulator	1
29	<u>1016904</u>	Gasket, Exhaust	1
30	<u>1017434</u>	Gasket, Head	1
31	<u>1017443</u>	Gasket, Crankcase Cover	1
32	<u>102753401</u>	Case, Rocker	1
Note: Item 28 is not a component of the FE350 engine.			

7

G




000205-002

AS11 FE350 ENGINE WITHOUT ACR – CRANKCASE, CAMSHAFT, AND OIL SENSOR

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1016454</u>	Bolt, Flange Head, M5 x 0.8 x 8 mm	2
2	<u>1016472</u>	Plate, Oil Filter Screen	1
3	<u>1016494</u>	Sensor, Oil Level	1
4	<u>1016496</u>	Screw, Cross Pan-Head, M4 x 0.7 x 8 mm	3
5	<u>1016506</u>	Clamp	1
6	<u>1016510</u>	Bracket, Switch, Oil Level	1
7	<u>1016521</u>	Screen, Oil Filter	1
8	<u>1016535</u>	Connector, Cord	1
9	<u>1016538</u>	O-Ring	2
10	<u>1016544</u>	Screw	1
11	<u>1016564</u>	Pin	2
12	<u>1016584</u>	Bolt, Two-Ended, M8 x 1.25 x 69 mm	2
13	<u>1017443</u>	Gasket, Crankcase Cover	1
14	<u>1017447</u>	Adjuster, Lash	2
15	<u>1017472</u>	Cover Crankcase	1
16	<u>1017487</u>	Bearing, Ball	1
17	<u>1017504</u>	Seal, Oil	1
18	<u>1017508</u>	Plug	1
19	<u>1017513</u>	Bolt Switch Bracket	2
20	<u>1017514</u>	Screw, M8-1.25 X 45mm Hex	6
21	<u>101751801</u>	Shim, 0.3	1
22	<u>101751802</u>	Shim, 0.4	1
23	<u>101751803</u>	Shim, 0.5	1
24	<u>102431001</u>	Camshaft, FE350 without ACR, 44-Tooth	1

7
G



000206-001

AS11 FE350 ENGINE – CRANKCASE AND CRANKSHAFT


ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	1016470	Shaft, Guide, Counterbalance	1
2	<u>1016541</u>	Stud, 6x14	4
3	1016547	Nut, M6 Flange	4
4	<u>1016571</u>	O-Ring	1
5	<u>101744901</u>	Piston, Standard	1
6	<u>101744902</u>	Piston, 0.50 mm Oversize	1
7	1017450	Pin, Piston	1
8	<u>101745101</u>	Ring Set, Standard Piston	1
9	<u>101745102</u>	Ring Set, Piston, 0.50 mm Oversize	1
10	<u>1017453</u>	Fe400 Counterbalance Weight (includes item 11)	1
11	1017510	Bearing, Plain	1
12	101745701	Asm, Con. Rod Std (includes item 13)	1
13	<u>1017512</u>	Bolt	2
14	<u>101745702</u>	Rod Assembly Connecting Rod 0.5mm (includes item 15)	1
15	<u>1017512</u>	Bolt	2
16	1017501	Spacer	1
17	<u>1017502</u>	Snap Ring	2
18	<u>1017503</u>	Seal, Oil	1
19	<u>101773301</u>	Shim, Crankshaft, 1.18mm	1
20	<u>101773302</u>	Shim, Crankshaft, 1.25mm	1
21	<u>101773303</u>	Shim, Crankshaft, 1.32mm	1
22	<u>101773304</u>	Shim, Crankshaft, 1.39mm	1
23	<u>101773305</u>	Shim, Crankshaft, 1.46mm	1
24	<u>101773306</u>	Shim, Crankshaft, 1.53mm	1
25	<u>101773307</u>	Shim, Crankshaft, 1.60mm	1
26	<u>101773308</u>	Shim, Crankshaft, 1.67mm	1
27	<u>101773309</u>	Shim, Crankshaft, 1.74mm	1
28	<u>101773310</u>	Shim, Crankshaft, 1.11mm	1
29	<u>101773311</u>	Shim, Crankshaft, 1.81mm	1
30	<u>101916001</u>	Crankcase Complete, FE350 (cw)	1
31	<u>102430901</u>	Crankshaft, FE350 Left-Hand, 22-Tooth (includes items 32 through 35)	1
32	<u>1016562</u>	Key	1
33	<u>1017471</u>	Rod	2
34	N/A	Gear, Helical	1
35	N/A	Gear, Spur	1

7

G

7

G



000200-003

FE350 ENGINE MOUNTING

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1010577</u>	Bolt, Hex-Head, 5/16-18 X 1.50	4
2	<u>1011697</u>	Washer, 5/16 Flat	2
3	<u>1012571</u>	Washer, 5/16 Extra Thick Flat	4
4	<u>1013924</u>	Nut, 5/16-24 Hex Head Cone	10
5	<u>101827101</u>	Plate, Engine Mounting	1
6	<u>101832601</u>	Stiffener (PTO Side)	1
7	<u>101832701</u>	Stiffener (Flywheel Side)	1
8	<u>101833101</u>	Stud, M8-1.25 X 50 mm Two-Ended	2
9	<u>101834601</u>	Snubber Bracket	1
10	<u>101884801</u>	Screw, 5/16-24 X 0.875 Grade-8	10
11	<u>101963401</u>	Locknut, 5/16-18 Hex Flange	4
12	<u>102065901</u>	Locknut, 3/8-16 Flanged Dimple	4
13	<u>102540301</u>	Inner Frame Snubber	1
14	<u>334</u>	Washer, 3/8 Type A Flat	4
15	<u>705</u>	Screw, Cap-hex Hd 3/8-16x1.25	4
16	<u>96704416</u>	Nut Flg, M8 X 1.25 Serrated	2

7

G


7

G

FUEL, INTAKE, AND GOVERNOR SYSTEMS

8

G




000449-001

FUEL SYSTEM

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1012649</u>	Clamp, 0.460 Red Hose	7
2	<u>1013687</u>	Clamp, 3/8" Hose (screw type)	1
3	<u>1013746</u>	Clamp, 0.301 ID Hose	2
4	<u>1015137</u>	Fuel Line (available by the foot)	1
5	<u>101824401</u>	Vent Barb	1
6	<u>102003201</u>	Filter, Fuel, 30 Micron	1
7	<u>102296020</u>	Screw, Torx Pan Hd Pt, M6 X 20	2
8	<u>102514201</u>	Hold-down - Fuel Tank	1
9	<u>102514701</u>	Bucket - Gas Vehicle	1
10	<u>102865101</u>	Fuel Line	1
11	103655002	Asm, Tank, Prec, Wo/su Nano (includes items 12 through 17)	1
12	<u>1015139</u>	Insulation Grommet	1
13	<u>1015143</u>	Vent, Fuel Tank	1
14	<u>102406701</u>	Bushing, Line, Return	1
15	<u>103372101</u>	Cap, Fuel Tank, Gas, Ratchet	1
16	<u>103372301</u>	Valve, Fuel, 259mm	1
17	103777001	Tank, Fuel, Prec, Nano	1
18	<u>103781101</u>	Kit, Fuel Pump Retrofit (includes items 19 and 20)	1
19	<u>103010101</u>	Pump, Fuel, Impulse, Fh	1
20	103781201	Instr, Fuel Pump Retrofit	1

8

G




000212-001

CARBURETOR ASSEMBLY – FE350

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101642575</u>	Jet, Altitude, # 75	1
2	<u>101642578</u>	Jet, Altitude, # 78	1
3	<u>101642580</u>	Jet, Altitude, # 80	1
4	<u>101642582</u>	Jet, Altitude, # 82	1
5	<u>101905901</u>	Carburetor, FE350D (includes items 6 through 15)	1
6	<u>101642585</u>	Jet, Altitude, # 85	1
7	<u>1016437</u>	Gasket, Carburetor Bowl OHV	1
8	<u>1016486</u>	Float Assembly	1
9	<u>1016501</u>	Screw Assembly	1
10	<u>1016585</u>	Bolt	1
11	<u>1017461</u>	Chamber Assembly, Float (includes item 12)	1
12	<u>1016499</u>	Screw Assembly	1
13	<u>101973101</u>	Jet, #40 Pilot	1
14	<u>101973301</u>	Nozzle, Main	1
15	N/A	Assembly, Pilot Air Screw	1
Note: <u>101642585</u> for 0 - 3,000 feet; <u>101642582</u> for 3,000 - 5,000 feet; <u>101642580</u> for 5,000 - 8,000 feet; <u>101642578</u> for 8,000 - 10,000 feet; <u>101642575</u> for 10,000 feet and higher.			

8


G



000213-002

CARBURETOR INSTALLATION – FE350


ITEM	PART NO.	DESCRIPTION	QTY	8
		1 2 3 4		G
1	<u>1011697</u>	Washer, 5/16 Flat	1	
2	<u>1013746</u>	Clamp, 0.301 ID Hose	1	
3	<u>1015137</u>	Fuel Line (available by the foot)	1	
4	<u>1016103</u>	Screw, Pan Hd Tx, Taptite 6-32	2	
5	<u>1016438</u>	Gasket, Carb To Intake Manifold	1	
6	<u>1016440</u>	Gasket, Engine to Insulator	1	
7	<u>1016441</u>	Gasket, Sprg Brkt To Carb OHV	1	
8	<u>1016444</u>	Bracket, Throttle Spring Return	1	
9	<u>1016480</u>	Pipe, Intake Manifold	1	
10	<u>101648102</u>	Insulator, Carburetor	1	
11	<u>101649002</u>	Stud, M6-1.00 Two-Ended	2	
12	<u>1016547</u>	Nut, M6 Flange	2	
13	<u>1016572</u>	Tube, Crankcase Vent	1	
14	<u>1016582</u>	Spring, Throttle Return	1	
15	<u>1017466</u>	Clamp	2	
16	<u>101820201</u>	Shield, Governor	1	
17	<u>101887601</u>	Locknut, M6-1.00 Nylon Insert	1	
18	<u>101973401</u>	Gasket, Insulator To Bracket	1	



000215-001

GOVERNOR AND ACCELERATOR CABLES

ITEM	PART NO.	DESCRIPTION	QTY	8
		1 2 3 4		G
1	<u>1011697</u>	Washer, 5/16 Flat	1	
2	<u>1012285</u>	Screw, 1/4 X 0.625 Hex-Head	4	
3	<u>1012830</u>	Screw, M8-125 X 22 Hex-Head	1	
4	<u>1013700</u>	Clamp	2	
5	<u>101584502</u>	Bracket, Governor Cable Snap-In	1	
6	<u>1016546</u>	Nut	2	
7	<u>101832202</u>	Bracket, Rear Governor Cable Snap-In	1	
8	<u>101832302</u>	Bracket, Rear Accelerator Cable Snap-In	1	
9	<u>102336001</u>	Cable, Governor, Snap-In	1	
10	<u>102513102</u>	Cable, Acc, Snap-in	1	
11	<u>7174</u>	Lockwasher, 5/16 Split	1	



CHOKE AND AIR BOX ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY	8
		1 2 3 4		G
1	<u>1014413</u>	Pin, Hair Spring Cotter	1	
2	<u>101811401</u>	Lever, Choke	1	
3	<u>101856201</u>	Compression Spring	1	
4	<u>102296020</u>	Screw, Torx Pan Hd Pt, M6 X 20	6	
5	<u>102297125</u>	Screw M6-1.0x25.4 Thd Fm Sems	2	
6	<u>102514401</u>	Rod, Choke Button	1	
7	<u>102521301</u>	Brace, Gas Fuel Bucket	1	
8	<u>102521401</u>	Support, Gas Bucket Brace	1	
9	<u>102588301</u>	Air Intake Assy (includes items 10 through 16)	1	
10	<u>102558201</u>	Air Filter, Precedent	1	
11	<u>102558301</u>	Clamp, Air Intake, Prec	2	
12	<u>102558401</u>	Hose, Air Intake, Prec	1	
13	<u>102558501</u>	Gasket, Air Intake, Prec	1	
14	<u>102558601</u>	Cover Asm, Air Intake, Prec	1	
15	<u>102558701</u>	Evac Valve, Air Intake, Prec	1	
16	N/A	Assembly, Body Intake (includes items 17 and 18)	1	
17	N/A	Filter Element, Air Intake	1	
18	N/A	Insert, Air Intake Body	1	


8

G

EXHAUST SYSTEM

9

G



000491-001

EXHAUST SYSTEM – FE350

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1012528</u>	Nut, M8-1.25 Hex	2
2	<u>1012830</u>	Screw, M8-125 X 22 Hex-Head	1
3	<u>1013734</u>	Lockwasher, 8mm Split	2
4	<u>1015814</u>	Bracket, Muffler Mounting	1
5	<u>1016904</u>	Gasket, Exhaust	1
6	<u>1017689</u>	Clamp, 5" Muffler Hose	1
7	<u>102585901</u>	Exhaust System, FE350, Precedent	1
8	<u>1241</u>	Washer, 5/16 Type A Flat	1
9	<u>332</u>	Washer, 1/4 Type A Narrow Flat	2
10	<u>451</u>	Lockwasher, 1/4 Split	2
11	<u>7174</u>	Lockwasher, 5/16 Split	1
12	<u>7847</u>	Screw, 1/4-20 X 0.75 Hex-Head Cap	2

9
G


9

G

TORQUE CONVERTER

10

G




000217-001

DRIVE CLUTCH

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101833902</u>	Clutch, Drive (includes items 2 through 28)	1
2	1014049	Bearing, Idler	1
3	<u>1014050</u>	Retainer, Spring	1
4	<u>1014051</u>	Spring, Drive Clutch	1
5	1014052	Movable-Face Assembly (includes items 6 through 8)	1
6	N/A	Drive Clutch Movable Face	1
7	<u>1014055</u>	Retainer	1
8	N/A	Bushing, Split, Drive Clutch	1
9	<u>1014056</u>	Ring, Spiral Backup	2
10	<u>1014057</u>	Ring, 0.810" Internal Retaining	1
11	1014058	Thrust Washer	1
12	1014059	Drive Hub Assy, Drive Clutch	1
13	<u>1014453</u>	Kit, Drive Clutch Button (includes items 14 through 17)	1
14	<u>1014062</u>	Driver, Drive Clutch	3
15	<u>1014287</u>	Spring, Drive Button	3
16	<u>183</u>	Washer, #10 Type A Flat	3
17	<u>8450</u>	Screw, #10-24 X 0.50 Hex-Head	3
18	<u>1016289</u>	Spacer, Fixed Face Shaft	1
19	<u>1016801</u>	Kit, Drive Clutch Weight (includes items 20 through 26)	1
20	<u>1014063</u>	Screw, 1/4-20 X 1.00 Hex Head	6
21	N/A	Pin, 0.3752 X 1.50 Dowel	3
22	<u>1014065</u>	Washer, 0.38" ID Delrin Flat	6
23	N/A	Clutch Weight, Secondary	3
24	N/A	Washer	6
25	<u>1016201</u>	Washer, Wave	3
26	N/A	Weight, Primary	3
27	<u>101925601</u>	Plug, Drive Clutch	3
28	<u>101929802</u>	Kit, Fxd Face Dr Asm Fe290/350 (includes items 29 and 30)	1
29	N/A	Desiccant Bag (Not Shown)	1
30	101929801	Assembly, Fixed-Face Drive (includes items 31 through 33)	1
31	N/A	Fixed Face Assembly, Drive Clutch	1
32	<u>1014288</u>	Screw, 5/16-18 X 0.75 Thread-Forming	3
33	N/A	Pulley, Clutch	1
34	<u>101916701</u>	V-Belt	1
35	<u>103345701</u>	Screw 3/8-24x5.5 Hex Loc Ptch	1
36	<u>808</u>	Washer, 3/8 Type B Flat	1
		Note: Item 29 not shown.	

10


G



000218-001

DRIVE BELT – FE290

ITEM	PART NO.	DESCRIPTION	QTY
1	<u>1016203</u>	1 2 3 4 Belt, Drive	1



000219-001

DRIVEN CLUTCH

ITEM	PART NO.	DESCRIPTION	QTY	10	G
		1 2 3 4			
1	<u>101834001</u>	Assembly, Driven Clutch (includes items 2 through 10)	1		
2	<u>1014070</u>	Fixed Face Assy, Driven Clutch	1		
3	<u>1014072</u>	Movable-Face Assembly with Bushing	1		
4	<u>1014078</u>	Key, Driven Clutch	1		
5	<u>1014080</u>	Ring, Retaining	1		
6	<u>1014454</u>	Kit, Driven Clutch Button (includes items 7 and 8)	1		
7	<u>1012836</u>	Screw, #8-32 X 3/4 Socket-Head Cap	3		
8	<u>1014076</u>	Button, Drive	3		
9	<u>1017686</u>	Cam, Driven Clutch	1		
10	<u>101836201</u>	Spring, Driven Clutch, Reversed	1		
11	<u>AM10419</u>	Kit, Clutch Repair (includes items 12 through 14)	1		
12	<u>101833401</u>	Key, 3/16 Sq X 1.50"	1		
13	<u>102155801</u>	Washer, Driven Clutch	1		
14	<u>102242101</u>	Screw, 5/16-18 X 3/4 Hex-Head with Patch	1		


10

G

UNITIZED TRANSAXLE

11

G




000220-002

UNITIZED TRANSAXLE – GEAR CASES AND BRACKETS

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1013061</u>	Locknut, #10-32 Nylon Insert	1
2	<u>1014007</u>	Washer, 1/4 Flat	1
3	<u>1017082</u>	Screw, #10-32 X 0.75, Hex-Head Machine	1
4	<u>1017231</u>	Key, Woodruff	1
5	<u>101833601</u>	Transaxle, 11.77 Ratio (includes items 6 through 24)	1
6	<u>1012711</u>	Breather	1
7	<u>1012752</u>	Roll Pin	1
8	<u>1012896</u>	Pin, Dowel	2
9	<u>1013760</u>	Fill Plug	2
10	<u>1016432</u>	Gasket, Drain Plug	1
11	<u>1016513</u>	Washer, M6 Flat	1
12	<u>101890101</u>	Lever, Change	1
13	<u>101890201</u>	Shaft - Change	1
14	<u>101890501</u>	Gear Case (driver side)	1
15	<u>101890601</u>	Gear Case (passenger side)	1
16	<u>101891301</u>	Arm Pivot	1
17	<u>101892901</u>	Washer	1
18	<u>101893801</u>	Washer	1
19	<u>101926901</u>	Screw, M8-1.25 X 40mm Hex-Head	15
20	<u>101927101</u>	Seal, Oil	1
21	<u>101927201</u>	Seal, Oil	1
22	<u>101927301</u>	Snap Ring	1
23	<u>101928601</u>	Pin, Cotter	1
24	<u>101928701</u>	Liquid Gasket (Transaxle case)	1
25	<u>101834801</u>	Arm, Governor	1
26	<u>101886101</u>	Screw, 1/4-20 X 1.00 Square-Head	1
27	<u>102515401</u>	Lever, Transmission Shift	1
28	<u>102526201</u>	Stud, Thread, 1/4-28	1
29	<u>183</u>	Washer, #10 Type A Flat	1
30	<u>8233</u>	Locknut, 1/4-20 Nylon Insert	1
31	<u>8717</u>	Locknut, 1/4-28 Nylon Insert	1
Note: Unitized transaxle component listings span several pages.			

11

G




000221-001

UNITIZED TRANSAXLE – F&R TRANSMISSION AND GEAR REDUCTION

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1012714</u>	Oil Seal	1
2	<u>1012740</u>	Synchro Insert	3
3	<u>1012741</u>	Synchro Spring	2
4	<u>1012747</u>	Shifter Ball	1
5	<u>1012748</u>	Shifter Spring	1
6	<u>1016337</u>	Washer, Thrust	1
7	<u>1016338</u>	Washer, Spring	2
8	<u>101889401</u>	Guide	1
9	<u>101890001</u>	Fork - Shift	1
10	<u>101891601</u>	Sleeve, Governor	1
11	<u>101891901</u>	Gear, Cluster	1
12	<u>101892001</u>	Rod, Shift	1
13	<u>101892201</u>	Plate, Thrust	3
14	<u>101892301</u>	Governor Assembly	1
15	<u>101892401</u>	Gear, Spur	1
16	<u>101892501</u>	Gear, Helical (61 Tooth)	1
17	<u>101892601</u>	Gear, Helical (17 Tooth)	1
18	<u>101893201</u>	Key Sunk	1
19	<u>101893901</u>	Washer	1
20	<u>101927501</u>	Needle Bearing	1
21	<u>101927601</u>	Needle Bearing	3
22	<u>101927701</u>	Pin, .116" Dia X 0.264 Dowel	1
23	<u>101927901</u>	Sleeve, Synchro	1
24	<u>101928001</u>	Hub, Synchro Clutch	1
25	<u>101928101</u>	Bearing, Ball	1
26	<u>101980801</u>	Gear Assembly, 16-Degree Synchro (25 Tooth)	1
27	<u>101980901</u>	Gear Assembly, 16-Degree Rear Synchro (28 Tooth)	1
28	<u>101981001</u>	Ring, 16-Degree Synchronizer	2
29	<u>102453001</u>	Shaft, Trans, with Circlip	1
30	<u>102453101</u>	Circlip	1
31	<u>7335</u>	Bearing	2
32	<u>AM10080</u>	Bearing, Ball, Sealed	2
33	<u>AM10081</u>	Bearing, Ball, Sealed	1

11
G




000222-001

TRANSAXLE – GASOLINE VEHICLES, DIFFERENTIAL AND AXLES

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1013770</u>	Differential Idler Gear	2
2	<u>1013771</u>	Gear, Differential	2
3	<u>1013772</u>	Pin, Differential	1
4	<u>1013794</u>	Axle Shaft Oil Seal	2
5	<u>1014193</u>	Dowel Pin	1
6	<u>101890901</u>	Pipe	1
7	<u>101891001</u>	Pipe	1
8	<u>101891401</u>	Axle Assembly, Passenger Side (includes items 9 through 13)	1
9	<u>1011291</u>	Outer Axle, Tube Bearing	1
10	<u>1013787</u>	Lug Stud	4
11	<u>1013792</u>	Circlip Type C	1
12	<u>1014207</u>	Bushing	1
13	<u>1016672</u>	Retaining Ring	1
14	<u>101891501</u>	Axle Assembly, Driver-Side (includes items 15 through 19)	1
15	<u>1011291</u>	Outer Axle, Tube Bearing	1
16	<u>1013787</u>	Lug Stud	4
17	<u>1013792</u>	Circlip Type C	1
18	<u>1014207</u>	Bushing	1
19	<u>1016672</u>	Retaining Ring	1
20	<u>101892701</u>	Gear, Helical	1
21	<u>101910501</u>	Kit, Differential Gear Case (includes items 22 through 25)	1
22	<u>1013768</u>	Differential Gear Case, Left-Hand	1
23	<u>1013769</u>	Differential Gear Case, Right-Hand	1
24	<u>1013773</u>	Plate, Thrust (Differential Gear)	1
25	<u>1013774</u>	Plate, Thrust (Idler Gear)	2
26	<u>101928301</u>	Screw, M8-1.25 X 35mm Hex Head	8
27	<u>102031901</u>	Bolt, M10 X 1.5 X 30mm	14
28	<u>7330</u>	Inner Axle Tube Bearing	2

11
G




000472-001

FORWARD/REVERSE SHIFTER ASSEMBLY – GASOLINE VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1012987</u>	Handle, FNR	1
2	<u>1015064</u>	Screw, #8-32 X 0.63 Machine	1
3	<u>102296040</u>	Screw, Torx Pan Hd Pt, M6 X 40	3
4	<u>102296920</u>	Screw, M6 Torx Bttn Hd Sems	2
5	<u>102512001</u>	Bezel, FNR Gas	1
6	<u>102514601</u>	Assembly - Gas F-n-r Shifter (includes items 7 through 24)	1
7	<u>1010954</u>	Stud, 1/4-28 X 0.560 Ball	1
8	<u>1012431</u>	Washer, #4 Flat	4
9	<u>1012594</u>	Screw, #4-40 Machine	2
10	<u>1013589</u>	Ring, 0.338" Internal Retaining	2
11	<u>1013590</u>	Spring, FNR Cam	1
12	<u>1013591</u>	Pin, 1/8 X 1/2 Roll	1
13	<u>1014065</u>	Washer, 0.38" ID Delrin Flat	1
14	<u>1014089</u>	Neutral Lockout Cam Kit (includes item 15)	1
15	<u>1014065</u>	Washer, 0.38" ID Delrin Flat	1
16	<u>1014145</u>	Bushing, Secondary Weight, Split	2
17	<u>1014727</u>	Washer, #4 Nylon Flat	2
18	<u>1014807</u>	Switch, Limit	1
19	<u>101979101</u>	Assembly, Switch, Limit	1
20	<u>102515301</u>	Weldment, F-n-r Gas	1
21	<u>102515601</u>	Base, Gas FNR Shifter	1
22	<u>8057</u>	Nut, #4-40 Hex Machine	4
23	<u>8058</u>	Lockwasher, #4 Split	2
24	<u>8717</u>	Locknut, 1/4-28 Nylon Insert	1
25	<u>102515501</u>	Bracket-trans Cable Support	1
26	<u>102554901</u>	Clip,edge,trans Shift Cable	1

11
G




000473-001

TRANSMISSION CABLE

ITEM	PART NO.	DESCRIPTION	QTY
1	<u>103379601</u>	1 2 3 4 Cable, Transmission, Prec	1

11

G




000490-001

ELECTRICAL COMPONENTS, FRONT BODY – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1012505</u>	Keys (set of 2)	1
2	<u>1016849</u>	Screw, #4-24 X 0.33 Pan-Head Machine	2
3	<u>1016851</u>	Buzzer, Reverse (9-48 VDC)	1
4	<u>101830701</u>	Nut, Key Switch	1
5	<u>101834502</u>	Cap, Black Key Switch	1
6	<u>101851101</u>	Washer, Key Switch	1
7	<u>102196901</u>	Dust Cap	1
8	<u>102508601</u>	Key Switch, Electric	1
9	<u>102508701</u>	Light, Battery	1
10	<u>102510001</u>	Ip Control Harness, Elec (includes item 11)	1
11	N/A	Connector, Cap 9-pin	1
12	<u>102522901</u>	Instrument Panel (standard)	1
13	<u>102536601</u>	Instrument Panel (with Hole for Headlight Switch)	1
14	<u>102536603</u>	Instrument Panel (with Hole for Battery Condition Indicator)	1
15	<u>102536605</u>	Instrument Panel (with Hole for Headlight Switch and Battery Condition Indicator)	1
16	<u>102572401</u>	Nut, Diagnostic Port, Prec	1
17	<u>AM10079</u>	Bulk Std Keys (50) *	1
		 * Note: Must order in multiples of 50.	


12

E

E

16 - PIN CONNECTOR AT CONTROLLER

000498-001



NOTE:
SOME WIRING / COMPONENTS SHOWN
ARE OPTIONAL ACCESSORIES

000498-001


See previous two pages for illustration.

WIRING – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>102510101</u>	Motor Sub-harness	1
2	<u>102550301</u>	Sub Harness Charger, Prec	1
3	<u>102585801</u>	Prec Elec Harness For 1510a	1
4	<u>102590001</u>	Prec Ce Tow-switch Diode	1
Note: Item 4 is used on vehicles going to the European Union.			

12

E




000462-001

FORWARD/REVERSE SWITCH AND TOW/RUN SWITCH – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101856002</u>	Switch, Rocker, Single-Pole	1
2	<u>101908401</u>	Boot, Switch	1
3	<u>102296716</u>	Screw, M6 X 16 Tt Hx Fl Hd	1
4	<u>102296920</u>	Screw, M6 Torx Bttn Hd Sems	2
5	<u>102508401</u>	Housing, FNR Electric	1
6	<u>102510901</u>	Cover, Electronics Module	1
7	<u>102511101</u>	Switch, Tow	1
8	<u>102520001</u>	Hour Meter/tow Switch Bkt	1
9	<u>102538601</u>	15 Amp Fuse	1
10	<u>102576801</u>	Diode Asm, Precedent	1

12


E



000731-001

SINGLE POINT WATERING SYSTEM

ITEM	PART NO.	DESCRIPTION	QTY	12
		1 2 3 4		
1	<u>102956301</u>	Kit Spws Prec Fr (includes items 2 through 9)	1	
2	<u>102956401</u>	Manifold, SPWS (Single-Point Watering System)	8	E
3	<u>102956501</u>	Assy Tube Single-Point Watering System, Precedent (includes items 4 through 8)	1	
4	<u>103226201</u>	Fitting Spws Swivel T	8	
5	<u>103226301</u>	O-ring Spws Swivel T	8	
6	<u>103226401</u>	Cap Spws Swivel T Red	9	
7	<u>103226601</u>	Coupler Male Spws Supply	1	
8	<u>103226701</u>	Tubing Spws	1	
9	N/A	Instr Spws Kit Prec Ds Fr	1	
10	<u>102958001</u>	Kit Regulated Hose Sply Spws	1	




BATTERIES, BUCKET, AND CHARGER RECEPTACLE – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1014304</u>	Nut, 5/16-18 Stainless-Steel Hex	8
2	<u>101831401</u>	Battery Cap 6 Volt	8
3	<u>102293512</u>	Screw-k35 Torx Pan Head Pt	3
4	<u>102298770</u>	M8-1.25x70 Taptite	2
5	<u>102509701</u>	Cable - Ev Passenger Jumper	1
6	<u>102509801</u>	Cable - Ev Rear Jumper	2
7	<u>102510201</u>	Receptacle Asm	1
8	<u>102510601</u>	Bucket-Electric Vehicle (not shown)	1
9	<u>102511301</u>	Battery, Ventmaster 12-Volt (Wet)	4
10	<u>102511302</u>	Battery, Ventmaster 12-Volt (Dry, also known as moist)	4
11	<u>102526401</u>	Support - Battery Clamp	2
12	<u>102526801</u>	Rod - Battery Clamp	2
13	<u>102534001</u>	Clamp - Battery	2
14	<u>102577001</u>	Kit, Bucket Closeout (includes items 15 through 17)	1
15	<u>1013357</u>	Rivet, 5/32 Aluminum Pop	2
16	N/A	Bracket, Bucket Closeout	2
17	N/A	Instr. Bucket Closeout	1
18	<u>102577002</u>	Kit, Bucket Closeout - 10 Sets (includes items 19 through 21)	1
19	<u>1013357</u>	Rivet, 5/32 Aluminum Pop	20
20	N/A	Bracket, Bucket Closeout	20
21	N/A	Instr. Bucket Closeout	1
22	<u>808</u>	Washer, 3/8 Type B Flat	2
23	<u>8754</u>	Locknut, 3/8-16 Hex	2

12

E



000486-001

COMPUTER, CONTROLLER, AND SOLENOID – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101908701</u>	Solenoid, 48-Volt (includes items 2 through 6)	1
2	<u>1012528</u>	Nut, M8-1.25 Hex	2
3	<u>1013734</u>	Lockwasher, 8mm Split	2
4	N/A	Solenoid, 48-Volt	1
5	N/A	Washer, Lock	2
6	N/A	Nut	2
7	<u>101956503</u>	Controller, 48-volt, IQ, CE Mark	1
8	<u>102240501</u>	Bolt, Controller, Terminal	3
9	<u>102296716</u>	Screw, M6 X 16 Tt Hx Fl Hd	13
10	<u>102510802</u>	Plate - Heat Sink Mntg Solnd	1
11	<u>102522701</u>	Asm, Pre-charge Resistor	1
12	<u>102806201</u>	Controller, IQ, 48-volt	1
13	<u>103262001</u>	Heat Sink Prec	1
14	<u>103403201</u>	Precedent V3.0 Obc	1
Note: Item 7 is for vehicles shipped to the European Union. Items 5 & 6 are not used in this application.			


12

E

ELECTRIC MOTOR

13

E




000349-001

MOTOR (MODEL 5BC59JBS6365) – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1010934</u>	Screw, 5/16-18 X 1.00 Hex Cap	1
2	<u>1014201</u>	Screw, 1/4-20 X 2.25 Hex Cap	3
3	<u>101920101</u>	Kit, 3-Pin Wedge Lock	1
4	<u>102235201</u>	Bumper, Drive Unit	1
5	<u>102240102</u>	Motor, 48-Volt Shunt-Wound * (includes items 6 through 31)	1
6	<u>1017944</u>	End Shield	1
7	<u>1017947</u>	Hardware Package (includes items 8 through 11)	1
8	<u>1011280</u>	Locknut, 5/16-18	4
9	N/A	Insulator Bushing	2
10	N/A	Insulated Bushing	2
11	<u>1241</u>	Washer, 5/16 Type A Flat	4
12	<u>1017949</u>	Screw, #6-32 X 0.480 Hex-Head	2
13	<u>1017950</u>	Bearing Retainer	1
14	<u>1017953</u>	Screw, Bearing Retainer	2
15	<u>102265501</u>	Stator Shell and Winding	1
16	<u>102265701</u>	Kit, Bearing and Magnet (includes items 17 and 18)	1
17	<u>1011290</u>	Ball Bearing	1
18	<u>102265801</u>	Magnet	1
19	<u>102265901</u>	Motor End Shield Asm (includes items 20 through 24)	1
20	<u>102265601</u>	Speed Sensor Assembly (includes items 21 and 22)	1
21	<u>101942301</u>	Kit, 3-Pin Wedge Lock	1
22	N/A	Sensor, Speed, without Connector	1
23	<u>102266001</u>	End Shield, Motor	1
24	<u>102267001</u>	Screw, #8-32 X 0.375 Hex-Head	1
25	<u>102266101</u>	Screw, #10 - 32 X 8.250	4
26	<u>102327801</u>	Brush Assembly, Beveled (includes items 27 through 30)	1
27	<u>1011411</u>	Kit, Brush Spring (ge Motor) (includes item 28)	1
28	<u>1011285</u>	Brush Spring	4
29	<u>1017948</u>	Brush Rigging	1
30	<u>102251901</u>	Brush Kit, Motor	1
31	N/A	Armature	1
32	<u>102243403</u>	Lubricant, Moly-Teflon (Single-Use Tube)	1
33	<u>451</u>	Lockwasher, 1/4 Split	3
34	<u>7174</u>	Lockwasher, 5/16 Split	1
* Note: The model 5BC59JBS6365 motor has been discontinued. To replace the motor, use motor model EJ8-4001A.			

13
E




000349-002

MOTOR (MODEL 5BC59JBS6390) – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1010934</u>	Screw, 5/16-18 X 1.00 Hex Cap	1
2	<u>1014201</u>	Screw, 1/4-20 X 2.25 Hex Cap	3
3	<u>101920101</u>	Kit, 3-Pin Wedge Lock	1
4	<u>102235201</u>	Bumper, Drive Unit	1
5	<u>102240104</u>	Motor, 48-Volt Non-Skew IQ * (includes items 6 through 27)	1
6	<u>1017944</u>	End Shield	1
7	<u>1017947</u>	Hardware Package (includes items 8 through 11)	1
8	<u>1011280</u>	Locknut, 5/16-18	4
9	N/A	Insulator Bushing	2
10	N/A	Insulated Bushing	2
11	<u>1241</u>	Washer, 5/16 Type A Flat	4
12	<u>1017949</u>	Screw, #6-32 X 0.480 Hex-Head	2
13	<u>1017950</u>	Bearing Retainer	1
14	<u>1017953</u>	Screw, Bearing Retainer	2
15	<u>102265701</u>	Kit, Bearing and Magnet (includes items 16 and 17)	1
16	<u>1011290</u>	Ball Bearing	1
17	<u>102265801</u>	Magnet	1
18	<u>102265901</u>	Motor End Shield Asm (includes items 19 through 23)	1
19	<u>102265601</u>	Speed Sensor Assembly (includes items 20 and 21)	1
20	<u>101942301</u>	Kit, 3-Pin Wedge Lock	1
21	N/A	Sensor, Speed, without Connector	1
22	<u>102266001</u>	End Shield, Motor	1
23	<u>102267001</u>	Screw, #8-32 X 0.375 Hex-Head	1
24	<u>102266101</u>	Screw, #10 - 32 X 8.250	4
25	<u>103325701</u>	Stator Shell and Winding	1
26	<u>103325801</u>	Non Skew Armature	1
27	<u>103337601</u>	Brush Assembly, IQ Motor, Non-Skew (includes items 28 through 31)	1
28	<u>1011411</u>	Kit, Brush Spring (ge Motor) (includes item 29)	1
29	<u>1011285</u>	Brush Spring	4
30	<u>103325501</u>	Brush Rigging, Non-Skew Motor	1
31	<u>103325601</u>	Brush Set, Non-Skew	1
32	<u>102243403</u>	Lubricant, Moly-Teflon (Single-Use Tube)	1
33	<u>451</u>	Lockwasher, 1/4 Split	3
34	<u>7174</u>	Lockwasher, 5/16 Split	1
* Note: The model 5BC59JBS6390 motor has been discontinued. To replace the motor, use motor model EJ8-4001A.			

13
E




000185-001

MOTOR (MODEL EJ4-4001) – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>1010934</u>	Screw, 5/16-18 X 1.00 Hex Cap	1
2	<u>1014201</u>	Screw, 1/4-20 X 2.25 Hex Cap	3
3	<u>101920101</u>	Kit, 3-Pin Wedge Lock	1
4	<u>102235201</u>	Bumper, Drive Unit	1
5	<u>102243403</u>	Lubricant, Moly-Teflon (Single-Use Tube)	1
6	<u>102705001</u>	IQ Electric Motor, 48-VDC 3.3 hp * (includes items 7 through 34)	1
7	<u>102186001</u>	Spring Kit, Motor Brush (includes item 8)	1
8	N/A	Spring, Brush, S-g	4
9	<u>102186101</u>	Brush Box Assembly	1
10	<u>102186201</u>	Brush Kit, Motor (includes item 11)	1
11	N/A	Assembly, Brush and Terminal	2
12	<u>102186301</u>	Ring, 2.24" Internal Retaining	1
13	<u>102186401</u>	Bearing, Ball	1
14	<u>102186701</u>	End Cap, Motor	1
15	N/A	Screw, 1/4-20 X 2.25 Hex-Head Washer	2
16	<u>102186901</u>	Screw, #8-32 X .5 Hex-Head	2
17	<u>102187001</u>	L-Bracket, Motor	1
18	<u>102187101</u>	Hardware Kit, Motor Terminal (includes items 19 through 22)	2
19	N/A	Bushing, Nylon	2
20	N/A	Washer, Nylon Flat	2
21	N/A	Washer, Flat, 5/16 Steel	2
22	N/A	Nut, Brass Hex, 5/16 - 18	2
23	<u>102187201</u>	Plate Kit, Motor Cover (includes items 24 and 25)	1
24	N/A	Assembly, Cover Plate	1
25	N/A	Screw, #8-32 x 0.375, Taptite Thread	1
26	<u>102704701</u>	Frame and Field Assembly	1
27	<u>102704801</u>	Armature Assembly	1
28	<u>102704901</u>	Kit, Speed Sensor (includes items 29 through 33)	1
29	<u>101942301</u>	Kit, 3-Pin Wedge Lock	1
30	N/A	Sensor, Motor Speed, ADC	1
31	N/A	Screw, #8-32, Taptite Thread	2
32	N/A	Magnet, ADC Motor	1
33	N/A	Screw, 1/4-20 x 0.5	1
34	N/A	Bolt, 1/4 - 20 x 0.73 Thread-Forming	2
35	<u>451</u>	Lockwasher, 1/4 Split	3
36	<u>7174</u>	Lockwasher, 5/16 Split	1
* Note: The model EJ4-4001 motor has been discontinued. To replace the motor, use motor model EJ8-4001A.			

13
E



000185-002

MOTOR (MODEL EJ8-4001A) – ELECTRIC VEHICLE

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	1014201	Screw, 1/4-20 X 2.25 Hex Cap	3
2	<u>101920101</u>	Kit, 3-Pin Wedge Lock	1
3	<u>102235201</u>	Bumper, Drive Unit	1
4	<u>102243403</u>	Lubricant, Moly-Teflon (Single-Use Tube)	1
5	N/A	IQ Electric Motor, 48-VDC 3.3 hp (includes items 6 through 26)	1
6	<u>102186001</u>	Spring Kit, Motor Brush (includes item 7)	1
7	N/A	Spring, Brush, S-g	4
8	<u>102186101</u>	Brush Box Assembly	1
9	<u>102186201</u>	Brush Kit, Motor (includes item 10)	1
10	N/A	Assembly, Brush and Terminal	2
11	<u>102186301</u>	Ring, 2.24" Internal Retaining	1
12	<u>102186401</u>	Bearing, Ball	1
13	<u>102186701</u>	End Cap, Motor	1
14	N/A	Screw, 1/4-20 X 2.25 Hex-Head Washer	2
15	<u>102186901</u>	Screw, #8-32 X .5 Hex-Head	2
16	<u>102187101</u>	Hardware Kit, Motor Terminal (includes items 17 through 20)	2
17	N/A	Bushing, Nylon	2
18	N/A	Washer, Nylon Flat	2
19	N/A	Washer, Flat, 5/16 Steel	2
20	N/A	Nut, Brass Hex, 5/16 - 18	2
21	<u>102187201</u>	Plate Kit, Motor Cover (includes items 22 and 23)	1
22	N/A	Assembly, Cover Plate	1
23	N/A	Screw, #8-32 x 0.375, Taptite Thread	1
24	<u>102704701</u>	Frame and Field Assembly	1
25	<u>102704801</u>	Armature Assembly	1
26	<u>102704901</u>	Kit, Speed Sensor (includes items 27 through 31)	1
27	<u>101942301</u>	Kit, 3-Pin Wedge Lock	1
28	N/A	Sensor, Motor Speed, ADC	1
29	N/A	Screw, #8-32, Taptite Thread	2
30	N/A	Magnet, ADC Motor	1
31	N/A	Screw, 1/4-20 x 0.5	1
32	<u>451</u>	Lockwasher, 1/4 Split	3


13

E

TRANSAXLE – ELECTRIC VEHICLES

14

E



000223-002

TRANSAXLE – ELECTRIC VEHICLES

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>102771701</u>	Transaxle, Electric (includes items 2 through 32)	1
2	<u>1013794</u>	Axle Shaft Oil Seal	2
3	<u>101895401</u>	Gear Case, Left-Hand	1
4	<u>101895501</u>	Gear Case, Passenger-Side	1
5	<u>101897001</u>	Screw, M8-1.25 X 60mm Hex-Head	11
6	<u>101897201</u>	Breather	1
7	<u>101897401</u>	Screw, M10-1.25 X 25mm	6
8	<u>101897601</u>	Pin, 11mm OD X 8.5mm ID X 10mm	2
9	<u>101903601</u>	Washer, Thrust	2
10	<u>101903701</u>	Washer, Thrust	2
11	<u>101906901</u>	Intermediate Shaft Assembly	1
12	<u>101922101</u>	Pin, 15.99mm X 88.7mm Dowel	1
13	<u>101923001</u>	Gear, Differential Idler	2
14	<u>101923201</u>	Gasket	2
15	<u>101923501</u>	Seal, Lip	1
16	<u>101923701</u>	Shaft, Input	1
17	<u>101923901</u>	Gear, Differential	2
18	<u>101928701</u>	Liquid Gasket (Transaxle case)	1
19	<u>101972101</u>	Plug, M14-1.5 X 12mm Magnetic	1
20	<u>101972201</u>	Plug, M14-1.5 X 12mm Hex	1
21	<u>102356601</u>	Housing, Differential, 6 Bolt	1
22	<u>102356801</u>	Gear, Differential Output, 6-Bolt	1
23	<u>102357001</u>	Screw, Flg Hd M10 X 1.5 X 30	10
24	<u>102886301</u>	Axle Assembly, Driver-Side (includes item 25)	1
25	<u>101922201</u>	Lug Stud	4
26	<u>102886401</u>	Tube, Axle, Driver-Side	1
27	<u>102886501</u>	Axle Assembly, Passenger-Side (includes item 28)	1
28	<u>101922201</u>	Lug Stud	4
29	<u>102886601</u>	Tube, Axle, Passenger-Side	1
30	<u>7330</u>	Inner Axle Tube Bearing	2
31	<u>7335</u>	Bearing	3
32	<u>7336</u>	Bearing	1

14


E

BATTERY CHARGER

15

E

E




POWERDRIVE 3 BATTERY CHARGER, DOMESTIC

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>103717001</u>	Chgr, Pd3 Stnry, 9Dc6'Ac'	1
2	<u>103717002</u>	Chgr, Pd3 Stnry, 12Dc9'Ac'	1
3	<u>103717003</u>	Chgr, Pd3 Stnry, 20Dc9'Ac'(includes items 4 through 27)	1
4	<u>102273701</u>	PD2 Fuse Asm	1
5	<u>102273801</u>	PD2 Ammeter	1
6	<u>103428501</u>	Kit, PD3 Cordset - AC 80" (includes item 7)	1
7	<u>102273901</u>	PD2 AC Cord Bushing	1
8	<u>103428601</u>	Kit, PD3 Cordset, - AC 114" (includes item 9)	1
9	<u>102273901</u>	PD2 AC Cord Bushing	1
10	<u>103428701</u>	Asm, PD3 Board Relay (includes item 11)	1
11	<u>103429701</u>	PD3 Plastic Stand-Offs	2
12	<u>103429001</u>	PD3 Cordset - DC 113" (includes item 13)	1
13	<u>1012098</u>	Bushing, DC Cord	1
14	<u>103429101</u>	PD3 Cordset - DC 154" (includes item 15)	1
15	<u>1012098</u>	Bushing, DC Cord	1
16	<u>103429201</u>	PD3 Cordset - DC 205" (includes item 17)	1
17	<u>1012098</u>	Bushing, DC Cord	1
18	<u>103429301</u>	Asm, PD3 Case (includes items 19 and 20)	1
19	<u>103434001</u>	Asm, PD3 Legs	1
20	<u>103439901</u>	PD3Case Top (Includes Handle)	1
21	<u>103429501</u>	Kit, PD3 Hardware	1
22	<u>103513001</u>	Wire Asm Kit Blk Pd3	1
23	<u>103517401</u>	Kit Pd3 Button Diode (includes items 24 and 25)	1
24	<u>103512801</u>	Asm Diode Top	1
25	<u>103512901</u>	Asm Diode Side	1
26	<u>103779601</u>	Transformer, Pd3, Al	1
27	<u>CCX8506</u>	Circuit Breaker, 15-Amp/120-Volt	1

15

E




000291-001

POWERDRIVE 2 BATTERY CHARGER (MODEL 22110), DOMESTIC

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101802204</u>	48-V/13-A PowerDrive 2 (9-ft. DC, 6-ft. AC)	1
2	<u>101802205</u>	48-V/13-A PowerDrive 2 (12-ft. DC, 9-ft. AC)	1
3	<u>101802206</u>	48-V/13-A PowerDrive 2 (20-ft. DC, 9-ft. AC) (includes items 4 through 23)	1
4	<u>1012098</u>	Bushing, DC Cord	1
5	<u>101828801</u>	Cord, AC, 80-Inch (203 cm)	1
6	<u>101828802</u>	Cord, AC, 108-Inch (274 cm)	1
7	<u>101828904</u>	PD2 DC Cordset, 113-inch	1
8	<u>101828905</u>	PD2 DC Cordset, 154-inch	1
9	<u>101828906</u>	Pd2 Dc Cordset 250 Inch	1
10	<u>102273201</u>	PD2 Case (includes item 11)	1
11	7577	Screw, #10 X 0.50 Phillips Pan-Head	12
12	<u>102273301</u>	PD2 Transformer Asm	1
13	<u>102273401</u>	PD2 Heatsink	1
14	<u>102273601</u>	PD2 Wire Asm	1
15	<u>102273701</u>	PD2 Fuse Asm	1
16	<u>102273801</u>	PD2 Ammeter	1
17	<u>102273901</u>	PD2 AC Cord Bushing	1
18	<u>102274001</u>	PD2 Handle	1
19	<u>103414901</u>	Kit, Relay, 48v 30a W/instr (includes items 20 and 21)	1
20	<u>103397901</u>	Relay, Spst No, 48v 30a, Pmt	1
21	N/A	Kit, Relay, 48v 30a Instrns	1
22	<u>103517601</u>	Pd2 Rectifier Kit	1
23	<u>CCX8506</u>	Circuit Breaker, 15-Amp/120-Volt	1
Note: Item 16 not shown. Level 1 Battery Charger part numbers include one AC and one DC cord. They do not include all of the level 2 cords listed.			

15

E




000351-001

POWERDRIVE BATTERY CHARGER (MODEL 17930), DOMESTIC

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101802201</u>	48V/17A PowerDrive (9-ft DC, 6-ft AC Cord)	1
2	<u>101802202</u>	48V/17A PowerDrive (12-ft DC, 9-ft AC Cord)	1
3	<u>101802203</u>	48V/17A PowerDrive (20-ft DC, 9-ft AC Cord) (includes items 4 through 22)	1
4	<u>1012098</u>	Bushing, DC Cord	1
5	<u>1012101</u>	Fuse Assembly	1
6	<u>1015914</u>	Rectifier with Heatsink Assembly	1
7	<u>1015917</u>	Bushing, AC Cord	1
8	****	Transformer, Battery Charger	1
9	<u>101828301</u>	Case Assembly	1
10	<u>101828501</u>	Ammeter	1
11	<u>101828801</u>	Cord, AC, 80-Inch (203 cm)	1
12	<u>101828802</u>	Cord, AC, 108-Inch (274 cm)	1
13	<u>101828901</u>	Cord, DC, 113-Inch (287 cm)	1
14	<u>101828902</u>	Cord, DC, 154-Inch (391 cm)	1
15	<u>101828903</u>	Cord, DC, 250-Inch (635 cm)	1
16	<u>101831101</u>	Wire Assembly Kit	1
17	101914401	Assembly, Voltage Suppressor	1
18	<u>103414901</u>	Kit, Relay, 48v 30a W/instr (includes items 19 and 20)	1
19	<u>103397901</u>	Relay, Spst No, 48v 30a, Pmt	1
20	N/A	Kit, Relay, 48v 30a Instrns	1
21	7577	Screw, #10 X 0.50 Phillips Pan-Head	10
22	<u>CCX8506</u>	Circuit Breaker, 15-Amp/120-Volt	1
		**** Special order item available upon request.	
		Note: Level 1 Battery Charger part numbers include one AC and one DC cord. They do not include all of the level 2 cords listed.	

15

E




000352-001

POWERDRIVE BATTERY CHARGER (MODEL 18780), EXPORT

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	101831503	Battery Charger, 48-Volt DC (8.5-ft DC, 6-ft AC)	1
2	101831504	Battery Charger, 48-Volt DC (12-ft DC, 9-ft AC) (includes items 3 through 20)	1
3	<u>1012098</u>	Bushing, DC Cord	1
4	<u>1012101</u>	Fuse Assembly	1
5	<u>1015914</u>	Rectifier with Heatsink Assembly	1
6	<u>1015917</u>	Bushing, AC Cord	1
7	<u>101828501</u>	Ammeter	1
8	<u>101828901</u>	Cord, DC, 113-Inch (287 cm)	1
9	<u>101828902</u>	Cord, DC, 154-Inch (391 cm)	1
10	<u>101831701</u>	Cord, AC, 80-Inch (203 cm), without Plug	1
11	<u>101831702</u>	Cord, AC, 118-Inch (203 cm), without Plug	1
12	101838201	Transformer, Export Battery Charger	1
13	<u>101838301</u>	Relay, Export Charger	1
14	101838401	Circuit Breaker	2
15	101838501	Kit, Wire Assembly	1
16	101838601	Four-Position Switch	1
17	****	Mounting Bracket, Relay	1
18	101914401	Assembly, Voltage Suppressor	1
19	N/A	Case, Charger	1
20	7577	Screw, #10 X 0.50 Phillips Pan-Head	10
**** Special order item available upon request. Note: Level 1 Battery Charger part numbers include one AC and one DC cord. They do not include all of the level 2 cords listed.			

15

E



POWERDRIVE BATTERY CHARGER (MODEL 20310), EUROPEAN

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	<u>101956201</u>	Battery Charger, 48-Volt w/ 4-Position Switch (8.5-ft DC)	1
2	<u>101956202</u>	Battery Charger, 48-Volt w/ 4-Pos. Switch (12-ft DC) (includes items 3 through 19)	1
3	<u>1012098</u>	Bushing, DC Cord	1
4	<u>1012101</u>	Fuse Assembly	1
5	<u>1015914</u>	Rectifier with Heatsink Assembly	1
6	<u>101828501</u>	Ammeter	1
7	<u>101828901</u>	Cord, DC, 113-Inch (287 cm)	1
8	<u>101828902</u>	Cord, DC, 154-Inch (391 cm)	1
9	<u>101838401</u>	Circuit Breaker	2
10	<u>101838601</u>	Four-Position Switch	1
11	<u>101973501</u>	Receptacle, AC Cord	1
12	<u>101987501</u>	Relay	1
13	N/A	Wire, Jumper	1
14	N/A	Case, Charger	1
15	****	Transformer, European Battery Charger	1
16	****	Suppressor, AC Voltage	1
17	****	Assembly, Wire	1
18	****	Limiter, Current	1
19	7577	Screw, #10 X 0.50 Phillips Pan-Head	10
20	<u>101958201</u>	Cord, UK, AC, Battery Charger	1
21	<u>101958301</u>	Cord, European AC, Battery Charger	1
**** Special order item available upon request.			
Note: Level 1 Battery Charger part numbers include one AC and one DC cord. They do not include all of the level 2 cords listed.			

15

E

15

E

MAINTENANCE AND SERVICE TOOLS

16

G

E


D

16

G

E

D




1



2



3




4




5



6




7



8




9




10




11



12




14 15
13




16



17



18



19

MAINTENANCE AND SERVICE TOOLS


ITEM	PART NO.	DESCRIPTION	QTY DIESEL	QTY GAS	QTY ELEC	16 G E D
		1 2 3 4 The following tool list includes all tools available from Club Car for maintenance and service procedures for gasoline, electric, and/or diesel vehicles, both past and present models. Be sure to carefully examine the tool list for applicability to your vehicle before ordering.				
1	<u>101871001</u>	Accelerator Pedal Adjustment Tool		1	1	
2	<u>101813202</u>	Adhesive, Guide Ring, 3-Gram Tube			1	
3	<u>101641202</u>	Arbor		1		
4	<u>101831901</u>	Battery Discharge Machine, 36/48 Volt			1	
5	<u>1014305</u>	Battery Terminal Protector Spray	1	1	1	
6	<u>1011767</u>	Battery Thermometer	1	1	1	
7	<u>1016417</u>	Bearing and Oil Seal Remover Assembly	1	1	1	
8	<u>1016416</u>	Bearing Driver Set	1	1	1	
9	<u>1012811</u>	Bearing Puller	1	1	1	
10	<u>1012812</u>	Bearing Puller Wedge Attachment	1	1	1	
11	<u>1013582</u>	Brake Adjustment Tool (used only on vehicles with manually adjusted mechanical brakes)		1	1	
12	<u>102555501</u>	Brake Cable Release Tool	1	1	1	
13	<u>102249901</u>	Brake Pedal Adjustment Tool Kit (used for the Carryall Electric Industrial Truck only) (includes items 14 and 15).....			1	
14	****	Brake Pedal Adjustment Tool			1	
15	****	Brake Pedal Tension Tool			1	
16	<u>101887101</u>	Calibration Test Module			1	
17	<u>101808401</u>	Cam Installation Tool		1		
18	<u>102562401</u>	Charger Bezel Tool			1	
19	<u>102686101</u>	Clutch Removal Tool (for 4x4 vehicles)	1	1		
		Please refer to the maintenance and service manual for proper tool application. **** Special order item available upon request				

16




G

E

D



20



MAINTENANCE AND SERVICE TOOLS, CONTINUED


ITEM	PART NO.	DESCRIPTION	QTY DIESEL	QTY GAS	QTY ELEC	16 G E D
		1 2 3 4				
20	<u>1014510</u>	Clutch Tool Kit (includes items 21 - 27)		1		
21	<u>1014498</u>	Clutch Alignment Tool (for pre-unitized transaxle vehicles built prior to 1997 model year)		1		
22	<u>1014496</u>	Drive Clutch Puller (for Kawasaki engines only)		1		
23	<u>1014497</u>	Drive Clutch Hub Puller (for Kawasaki engines only)		1		
24	<u>1014508</u>	Driven Clutch Cam Puller (for Kawasaki engines only)		1		
25	<u>1014507</u>	Driven Clutch Puller Plug (for Kawasaki engines only)		1		
26	<u>1015524</u>	Drive Clutch Holder Tool Assembly (for Kawasaki engines only)		1		
27	<u>101809101</u>	Press Weldment (for Kawasaki engines only)		1		
28	<u>102601501</u>	Drive ClutchFixed Sheave Tool (for 4x4 vehicles)	1	1		
29	<u>102603501</u>	Driven Clutch Spring Compression Base (for use with items 30 and 31) (for 4x4 vehicles)	1	1		
30	<u>102605201</u>	Driven Clutch Spring Compression Collar (for use with items 29 and 31) (for 4x4 vehicles)	1	1		
31	<u>102606101</u>	Driven Clutch Spring Compression Nut (for use with items 29 and 30) (for 4x4 vehicles)	1	1		
32	<u>102607501</u>	Drive Clutch Spider Removal Tool (for 4x4 vehicles)	1	1		
33	101831801	Communication Display Module			1	
34	101641002	Compression Gauge and Adapter		1		
35	1011273	Continuity Tester		1	1	
36	<u>102773801</u>	Cutter, Valve Seat, #122		1		
37	<u>102773901</u>	Cutter, Valve Seat #115		1		
38	<u>102774101</u>	Wrench, T, #505.....		1		
39	<u>102774101</u>	Adapter, T-Wrench		1		
40	102675401	Cutter, Valve Seat, 60 Degree (requires item 51) (for Honda GX620 Gasoline Engines)		1		
41	<u>102774201</u>	Pilot, 6.6 MM		1		
42	<u>102774301</u>	Pilot, 6.62 MM.....		1		
43	<u>102774401</u>	Pilot, 6.65 MM.....		1		
		Please refer to the maintenance and service manual for proper tool application.				

16


G

E


D




44



45




46




47



48




49



50



51




52

53

55

54



56



58




59

60



61



57

MAINTENANCE AND SERVICE TOOLS, CONTINUED

ITEM	PART NO.	DESCRIPTION	QTY DIESEL	QTY GAS	QTY ELEC	16 G E D
		1 2 3 4				
44	<u>1012151</u>	Dry Moly Lubricant	1	1	1	
45	<u>1016627</u>	Flywheel Puller Kit (for Kawasaki Engines)		1		
46	<u>102669901</u>	Gauge, Carburetor Float Level (for Honda GX620 Gasoline Engines)		1		
47	<u>1016418</u>	Gear Yoke	1	1	1	
48	<u>101933101</u>	Governor Shaft Installation Tool (for Kawasaki Engine Vehicles)		1		
49	<u>102169401</u>	Hydraulic Brake Adjuster (for Turf/CA 272/472, Pioneer/XRT 1200, Bobcat 2100, HUV 4213)			1	
50	<u>1011478</u>	Hydrometer	1	1	1	
51	<u>1013593</u>	Internal Retaining Ring Pliers	1	1	1	
52	<u>102248803</u>	IQ Display Module (IQDM) Kit (IQ System and IQ Plus vehicles)			1	
		(includes items 54 and 55)				
53	<u>102248804</u>	IQ Display Module (IQDM-P) Kit (IQ System and IQ Plus vehicles)			1	
		(includes items 54 and 55)				
54	<u>102251501</u>	Adaptor, Cable			1	
55	<u>102241502</u>	IQDM Series 2 Cable			1	
56	<u>102241501</u>	IQDM Series 1 Cable (replacement)			1	
57	<u>101928701</u>	Liquid Gasket (transaxle case)	1	1	1	
58	<u>102243402</u>	Moly-Teflon Lubricant (4-oz. (113-gram) tube)			1	
59	<u>101997201</u>	Paint, Touch-Up – Beige*		1	1	
59	<u>101997207</u>	Paint, Touch-Up – Black*		1	1	
59	<u>101997212</u>	Paint, Touch-Up – Burgundy*		1	1	
59	<u>101997211</u>	Paint, Touch-Up – Classic Blue (Navy)*		1	1	
59	<u>101997205</u>	Paint, Touch-Up – Dark Gray*	1	1	1	
59	<u>101997209</u>	Paint, Touch-Up – Dark Green*	1	1	1	
59	<u>101997204</u>	Paint, Touch-Up – Gray*	1	1	1	
59	<u>101997203</u>	Paint, Touch-Up – Red*	1	1	1	
59	<u>101997206</u>	Paint, Touch-Up – Royal Blue (Pacific Blue)*		1	1	
59	<u>101997202</u>	Paint, Touch-Up – White*	1	1	1	
60	<u>102562301</u>	Paint, Precedent Underbody – Gray		1	1	
61	<u>102587201</u>	Paint Pen, Touch-Up, Precedent Underbody – Black		1	1	
Please refer to the maintenance and service manual for proper tool application. * Item 59 is not for use on Surlyn[®] body material, which is used on Precedent vehicles.						

16


G

E


D



62



63




64



65



66



67



68




69



70




71



72



73




74




75



76



77



83



84



85




86

MAINTENANCE AND SERVICE TOOLS, CONTINUED


ITEM	PART NO.	DESCRIPTION	QTY DIESEL	QTY GAS	QTY ELEC	16 G E D
		1 2 3 4				
62	<u>1016414</u>	Piston Ring Compressor Kit (FE290, FE350 and FE400 engines)		1		
63	<u>1016415</u>	Piston Ring Pliers (for Kawasaki Engines)		1		
64	<u>102668801</u>	Puller, Special Use (for Kubota D722 Diesel Engines)	1			
65	<u>1012549</u>	Retaining Ring Pliers, 45° External	1	1	1	
66	<u>1012560</u>	Retaining Ring Pliers, 90° Internal	1	1	1	
67	<u>101823101</u>	Safety First Card (50 per pack)	1	1	1	
68	<u>1012809</u>	Seal Puller	1	1	1	
69	<u>102330901</u>	Spanner Wrench (for coil over shock front suspension vehicles only)	1	1		
70	<u>1014264</u>	Steering Column Bearing Press Tool		1	1	
71	<u>1014259</u>	Steering Column Retaining Ring Tool		1	1	
72	<u>102061201</u>	Steering Wheel Puller Tool	1	1	1	
73	<u>AM10753</u>	Tachometer (includes gasoline engine pick up lead only)	1	1		
74	<u>AM10771</u>	Tachometer Diesel Probe (for use with item 73)	1			
75	<u>1014162</u>	Transaxle Axle Seal Tool		1		
76	<u>1014161</u>	Transaxle Pinion Seal Tool		1		
77	<u>1014115</u>	Transmission Tool Kit		1		
78	<u>101611003</u>	Tune-Up Kit, All OHV (for FE290, FE350, FE400 only) (includes air filter, spark plug, oil filter, fuel filters) (not shown)		1		
79	<u>AM11804</u>	Tune-Up Kit, Gx620 (for Honda Engines) (includes air filter, spark plug, oil filter, fuel filters) (not shown)		1		
80	<u>AM11805</u>	Tune-Up Kit, D722 (for Kubota Engines) (includes air filter, oil filter, fuel filters, water separator filter) (not shown)	1			
81	<u>AM1220301</u>	Tune-Up Kit, Precedent (for FE290/350 Engines) (includes air filter, spark plug, oil filter, fuel filters) (not shown)		1		
82	<u>AM1232401</u>	Tune-Up Kit, FH680D (for Kawasaki V-Twin Engines) (includes oil filter, fuel filter, air filter, and spark plugs) (not shown).....		1		
83	<u>1016413</u>	Valve Clearance Adjuster Screw Holder (for FE290 engines only)		1		
84	<u>102674601</u>	Valve Guide Driver (for Honda GX620 Gasoline Engines)		1		
85	<u>101641201</u>	Valve Guide Reamer (FE290, FE350, and FE400 only)		1		
86	<u>102674401</u>	Valve Guide Reamer, 6.6 mm (for Honda GX620 Gasoline Engines)		1		




87




88




89




90



91




92




93



94



95



96

MAINTENANCE AND SERVICE TOOLS, CONTINUED

ITEM	PART NO.	DESCRIPTION	QTY DIESEL	QTY GAS	QTY ELEC	16 G E D
		1 2 3 4				
87	<u>1016552</u>	Valve Seat Cutter Guide		1		
88	<u>1016551</u>	Valve Seat Cutter T-Wrench		1		
89	<u>1016553</u>	Valve Seat Cutter, 45° (32 mm diameter) (for FE290 engines only)		1		
90	<u>1016554</u>	Valve Seat Cutter, 45°/30° (35 mm diameter)		1		
91	<u>101641101</u>	Valve Spring Compressor		1		
92	<u>1011480</u>	Volt Ohm Meter	1	1	1	
93	<u>102570401</u>	Tool, Tensioning, Starter Generator (For Precedent vehicles)		1		
94	<u>103601401</u>	Puller, Drive Clutch, XRT 950*		1		
95	<u>103601701</u>	Tool, Disassembly, Driven Clutch, XRT 950		1		
96	<u>103600501</u>	Screw, Driven Clutch Disassembly, M6, XRT 950		1		
*Note: The XRT 950 Drive Clutch Puller requires the use of Screw, Driven Clutch Disassembly, CCI Part Number <u>103600501</u>.						

INDEX

Part Number and Page

AM10753	16-9	1012098	15-3, 15-5, 15-7, 15-9, 15-11	1013774	11-7
AM10771	16-9	1012101	15-7, 15-9, 15-11	1013787	11-7
AM10079	6-3, 12-3	1012151	16-7	1013792	11-7
AM10080	11-5	1012180	5-17, 5-19	1013794	11-7, 14-3
AM10081	11-5	1012181	5-17, 5-19, 5-21	1013924	4-3, 7-15
AM10419	10-7	1012182	5-17, 5-19, 5-21	1014007	11-3
AM10724	7-5	1012285	8-9	1014049	10-3
CCX8506	15-3, 15-5, 15-7	1012295	6-5	1014050	10-3
183	10-3, 11-3	1012431	11-9	1014051	10-3
332	9-3	1012505	6-3, 12-3	1014052	10-3
334	7-15	1012528	9-3, 12-15	1014055	10-3
451	9-3, 13-3, 13-5, 13-7, 13-9	1012549	16-9	1014056	10-3
705	7-15	1012560	16-9	1014057	10-3
706	5-15	1012565	5-3, 5-5	1014058	10-3
808	10-3, 12-13	1012566	5-3, 5-5	1014059	10-3
1241	6-17, 9-3, 13-3, 13-5	1012571	7-15	1014062	10-3
1242	4-7, 4-9, 6-5, 6-17	1012594	11-9	1014063	10-3
1624	6-17	1012649	8-3	1014065	10-3, 11-9
7174	6-17, 8-9, 9-3, 13-3, 13-5, 13-7	1012711	11-3	1014070	10-7
7310	2-3, 2-5	1012714	11-5	1014072	10-7
7330	11-7, 14-3	1012740	11-5	1014076	10-7
7335	11-5, 14-3	1012741	11-5	1014078	10-7
7336	14-3	1012747	11-5	1014080	10-7
7577	15-5, 15-7, 15-9, 15-11	1012748	11-5	1014089	11-9
7847	9-3	1012752	11-3	1014115	16-9
7893	6-5	1012809	16-9	1014145	11-9
8057	11-9	1012811	16-3	1014153	4-3
8058	11-9	1012812	16-3	1014161	16-9
8233	11-3	1012830	6-17, 8-9, 9-3	1014162	16-9
8450	10-3	1012836	10-7	1014193	11-7
8717	11-3, 11-9	1012896	11-3	1014201	13-3, 13-5, 13-7, 13-9
8745	5-15	1012987	11-9	1014207	11-7
8754	6-17, 12-13	1012991	6-15	1014259	16-9
1010142	5-17, 5-19, 5-21	1013001	6-15	1014264	16-9
1010144	5-17, 5-19, 5-21	1013003	6-15	1014287	10-3
1010145	5-17, 5-19, 5-21	1013005	6-15	1014288	10-3
1010434	1-7, 1-9, 1-17, 1-29, 1-31, 1-33, 1-35, 1-37, 4-7, 4-9	101301102	6-15	1014289	6-15
1010577	7-15	1013061	11-3	1014304	12-13
1010829	4-5	1013357	12-13	1014305	16-3
1010934	13-3, 13-5, 13-7	1013582	16-3	1014375	6-5
1010953	4-3	1013589	11-9	1014413	1-11, 8-11
1010954	11-9	1013590	11-9	1014453	10-3
1010984	2-3	1013591	11-9	1014454	10-7
1011273	16-5	1013593	16-7	1014496	16-5
1011280	13-3, 13-5	1013609	6-5	1014497	16-5
1011285	13-3, 13-5	1013687	8-3	1014498	16-5
1011290	13-3, 13-5	1013700	8-9	1014507	16-5
1011291	11-7	1013734	9-3, 12-15	1014508	16-5
1011411	13-3, 13-5	1013746	8-3, 8-7	1014510	16-5
1011415	5-17, 5-19, 5-21	1013760	11-3	1014555	5-17, 5-19, 5-21
1011478	16-7	1013768	11-7	1014727	11-9
1011480	16-11	1013769	11-7	1014807	11-9
1011697	7-15, 8-7, 8-9	1013770	11-7	1014902	1-33, 1-35, 1-37, 5-21
1011767	16-3	1013771	11-7	1015064	11-9
		1013772	11-7	1015137	8-3, 8-7
		1013773	11-7	1015139	8-3

INDEX

1015143	8-3	1016472	7-11	1016585	8-5
101524002	6-17	1016473	7-7	1016586	7-5
1015332	7-3	1016474	7-9	1016587	7-5
1015524	16-5	1016479	7-9	1016588	7-5
1015649	7-3	1016480	8-7	1016627	16-7
1015814	9-3	101648102	8-7	1016630	6-3
101584502	8-9	101648203	7-7	1016663	5-3, 5-5
1015914	15-7, 15-9, 15-11	1016483	7-9	1016672	11-7
1015917	15-7, 15-9	1016486	8-5	1016801	10-3
1015932	6-17	1016489	7-9	1016849	6-3, 12-3
1015969	7-3	101649002	8-7	1016851	6-3, 12-3
1016074	6-17	1016494	7-11	1016883	6-17
1016103	8-7	1016496	7-11	1016904	7-9, 9-3
101611003	16-9	1016497	7-5	101705701	1-33, 1-35, 1-37, 3-7
1016154	5-3, 5-5	1016499	8-5	1017082	11-3
101615602	5-5	1016501	8-5	1017231	11-3
1016201	10-3	1016502	7-7	1017235	1-33, 1-35, 1-37, 5-21
1016203	10-5	1016506	7-11	1017434	7-9
1016219	5-5	1016507	7-3	1017435	7-9
1016289	10-3	1016510	7-11	1017442	7-7
1016337	11-5	1016513	11-3	1017443	7-9, 7-11
1016338	11-5	1016517	7-9	1017444	7-9
101641002	16-5	1016518	7-9	1017445	7-9
101641101	16-11	1016519	7-9	1017446	7-9
101641201	16-9	1016521	7-11	1017447	7-11
101641202	16-3	1016531	7-3	1017448	7-5
1016413	16-9	1016535	7-11	101744901	7-13
1016414	16-9	1016537	7-7	101744902	7-13
1016415	16-9	1016538	7-11	1017450	7-13
1016416	16-3	1016539	7-3	101745101	7-13
1016417	16-3	1016541	7-13	101745102	7-13
1016418	16-7	1016544	7-5, 7-9, 7-11	1017453	7-13
101642575	8-5	1016546	8-9	1017454	7-9
101642578	8-5	1016547	7-3, 7-13, 8-7	1017455	7-5
101642580	8-5	1016549	7-9	1017456	7-7
101642582	8-5	1016551	16-11	101745701	7-13
101642585	8-5	1016552	16-11	101745702	7-13
1016429	7-7	1016553	16-11	1017458	7-7
1016432	7-7, 11-3	1016554	16-11	1017460	7-7
1016436	7-9	1016560	7-9	1017461	8-5
1016437	8-5	1016561	7-5	1017463	7-5
1016438	8-7	1016562	7-5, 7-13	1017466	8-7
1016440	7-9, 8-7	1016563	7-9	1017468	7-5
1016441	8-7	1016564	7-11	1017471	7-13
1016444	8-7	1016566	7-9	1017472	7-11
1016445	7-5	1016569	7-9	1017473	7-9
1016449	7-9	1016570	7-7	1017474	7-3
1016450	7-9	1016571	7-13	1017475	7-3
1016452	7-9	1016572	8-7	1017476	7-3
1016454	7-11	1016576	7-7	1017486	7-3
1016455	7-5	1016578	7-5	1017487	7-11
1016456	7-3, 7-5	1016579	7-5	1017490	7-5
1016457	7-7	1016581	7-7	1017500	7-3
1016458	7-9	1016582	8-7	1017501	7-13
1016467	7-7	1016583	7-9	1017502	7-13
1016470	7-13	1016584	7-11	1017503	7-13

INDEX

1017504	7-11	101828802	15-5, 15-7	101876501	6-15
1017507	7-7	101828901	15-7, 15-9, 15-11	101877601	6-15
1017508	7-11	101828902	15-7, 15-9, 15-11	101877701	6-15
1017510	7-13	101828903	15-7	101878101	6-15
1017512	7-13	101828904	15-5	101879001	6-15
1017513	7-11	101828905	15-5	101881101	7-5
1017514	7-11	101828906	15-5	101884801	7-15
101751801	7-11	101830701	6-3, 12-3	101886101	11-3
101751802	7-11	101831101	15-7	101887101	16-3
101751803	7-11	101831401	12-13	101887601	7-3, 8-7
1017653	6-15	101831503	15-9	101889401	11-5
1017686	10-7	101831504	15-9	101890001	11-5
1017689	9-3	101831701	15-9	101890101	11-3
101773301	7-13	101831702	15-9	101890201	11-3
101773302	7-13	101831801	16-5	101890501	11-3
101773303	7-13	101831901	16-3	101890601	11-3
101773304	7-13	101832202	8-9	101890901	11-7
101773305	7-13	101832302	8-9	101891001	11-7
101773306	7-13	101832601	7-15	101891301	11-3
101773307	7-13	101832701	7-15	101891401	11-7
101773308	7-13	101833101	7-15	101891501	11-7
101773309	7-13	101833401	10-7	101891601	11-5
101773310	7-13	101833601	11-3	101891901	11-5
101773311	7-13	101833701	6-15	101892001	11-5
101791101	4-3	101833902	10-3	101892201	11-5
1017944	13-3, 13-5	101834001	10-7	101892301	11-5
1017947	13-3, 13-5	101834502	6-3, 12-3	101892401	11-5
1017948	13-3	101834601	7-15	101892501	11-5
1017949	13-3, 13-5	101834801	11-3	101892601	11-5
1017950	13-3, 13-5	101836201	10-7	101892701	11-7
1017953	13-3, 13-5	101837301	6-17	101892901	11-3
101802201	15-7	101838201	15-9	101893201	11-5
101802202	15-7	101838301	15-9	101893801	11-3
101802203	15-7	101838401	15-9, 15-11	101893901	11-5
101802204	15-5	101838501	15-9	101895401	14-3
101802205	15-5	101838601	15-9, 15-11	101895501	14-3
101802206	15-5	101851101	6-3, 12-3	101896501	6-15
101808401	16-3	101856002	12-9	101897001	14-3
101809101	16-5	101856201	1-11, 8-11	101897201	14-3
101811401	1-11, 8-11	101869302	6-15	101897401	14-3
101813202	16-3	101871001	16-3	101897601	14-3
101815501	4-3	101874901	6-15	101898001	6-5
101815502	4-3	101875001	6-15	101903601	14-3
101816401	4-3	101875101	6-15	101903701	14-3
101816501	4-3	101875102	6-15	101905901	8-5
101816502	4-3	101875201	6-15	101906901	14-3
101820201	8-7	101875301	6-15	101908401	12-9
101823101	16-9	101875401	6-15	101908701	12-15
101823201	4-3	101875501	6-15	101909201	7-5
101823801	4-3	101875601	6-15	101909301	7-5
101824401	8-3	101875701	6-15	101909401	7-5
101825101	3-3, 3-5	101875802	6-15	101909501	7-5
101827101	7-15	101876001	6-15	101910501	11-7
101828301	15-7	101876202	6-15	101914401	15-7, 15-9
101828501	15-7, 15-9, 15-11	101876301	6-15	101916001	7-13
101828801	15-5, 15-7	101876402	6-15	101916101	7-3

INDEX

101916201	7-5	101980901	11-5	102287701	5-13
101916301	7-5	101981001	11-5	102287901	5-15
101916701	6-17, 10-3	101987501	15-11	102288101	5-13, 5-15
101920101	13-3, 13-5, 13-7, 13-9	102003201	8-3	102288201	5-15
101922101	14-3	102022601	5-11	102288401	5-15
101922201	14-3	102031901	11-7	102288601	5-11
101923001	14-3	102061201	16-9	102288901	5-13
101923201	14-3	102065901	7-15	102289001	5-11
101923501	14-3	102155801	10-7	102289101	5-15
101923701	14-3	102169401	16-7	102289201	5-11, 5-15
101923901	14-3	102186001	13-7, 13-9	102289301	5-11, 5-15
101925601	10-3	102186101	13-7, 13-9	102289401	5-13
101926901	11-3	102186201	13-7, 13-9	102289501	5-13, 5-15
101927101	11-3	102186301	13-7, 13-9	102289601	5-13
101927201	11-3	102186401	13-7, 13-9	102289701	5-13
101927301	11-3	102186701	13-7, 13-9	102289801	5-15
101927501	11-5	102186901	13-7, 13-9	102289901	5-13
101927601	11-5	102187001	13-7	102290120	5-3, 5-7, 5-9
101927701	11-5	102187101	13-7, 13-9	102292201	4-7, 4-9
101927901	11-5	102187201	13-7, 13-9	102292356	1-7, 1-9
101928001	11-5	102196901	12-3	102292701	1-9, 1-19
101928101	11-5	102235201	13-3, 13-5, 13-7, 13-9	102292801	4-5
101928301	11-7	102240102	13-3	102293512	12-13
101928601	11-3	102240104	13-5	102296020	1-5, 6-5, 8-3, 8-11
101928701	11-3, 14-3, 16-7	102240501	12-15	102296040	6-5, 11-9
101929801	10-3	102241501	16-7	102296140	1-25, 1-27
101929802	10-3	102241502	16-7	102296401	1-25, 1-27
101933101	16-7	102242101	10-7	102296530	1-17, 1-29, 1-33, 1-35, 1-37
101939901	6-15	102243402	16-7	102296601	1-9, 1-19
101942301	13-3, 13-5, 13-7, 13-9	102243403	13-3, 13-5, 13-7, 13-9	102296716	12-9, 12-15
101953802	7-3	102248803	16-7	102296819	1-7
101956201	15-11	102249901	16-3	102296920	1-9, 11-9, 12-9
101956202	15-11	102251501	16-7	102297125	1-17, 8-11
101956503	12-15	102251901	13-3	102297230	1-19
101958201	15-11	102265501	13-3	102297901	4-7, 4-9
101958301	15-11	102265601	13-3, 13-5	102298020	1-9
101960501	3-3	102265701	13-3, 13-5	102298030	1-11, 1-13, 1-19, 1-29, 4-7, 4-9
101963401	7-15	102265801	13-3, 13-5	102298116	5-7, 5-9
101972001	16-7	102265901	13-3, 13-5	102298130	5-7, 5-9
101972002	16-7	102266001	13-3, 13-5	102298170	5-17, 5-19, 5-21
101972003	16-7	102266101	13-3, 13-5	102298185	5-17, 5-19, 5-21
101972004	16-7	102267001	13-3, 13-5	102298240	1-17, 1-19, 1-29
101972005	16-7	102273201	15-5	102298401	1-3, 1-25, 1-27, 5-17, 5-19, 5-21
101972006	16-7	102273301	15-5	102298580	1-19
101972007	16-7	102273401	15-5	102298601	1-19
101972009	16-7	102273601	15-5	102298716	1-9, 1-19
101972011	16-7	102273701	15-3, 15-5	102298720	1-29, 1-31, 1-33, 1-35, 1-37
101972012	16-7	102273801	15-3, 15-5	102298745	1-31, 1-33, 1-35, 1-37
101972101	14-3	102273901	15-3, 15-5	102298770	12-13
101972201	14-3	102274001	15-5	102299065	1-21, 1-25, 1-27
101973101	8-5	102279001	1-19	102299360	1-25, 1-27
101973301	8-5	102279103	1-19	102299601	1-25, 1-27
101973401	8-7	102279104	1-19	102302504	1-9
101973501	15-11	102287101	5-13	102302604	1-9
101979101	11-9	102287201	5-15	102304801	7-9
101980801	11-5	102287601	5-13	102327801	13-3

INDEX

102330901	16-9	102504201	1-17	102519301	3-3, 3-5
102336001	8-9	102504301	1-17	102519401	3-5
102353201	5-15	102504501	1-17	102520001	12-9
102353301	5-15	102504802	1-9	102520701	1-27
102355301	6-5	102505701	5-13	102520702	1-25
102356601	14-3	102506201	5-17, 5-19, 5-21	102521301	8-11
102356801	14-3	102506301	5-17, 5-19, 5-21	102521401	8-11
102357001	14-3	102506401	5-17, 5-19, 5-21	102521901	1-9
102380401	1-7	102506601	5-17, 5-19, 5-21	102522604	2-3
102400002	1-25, 1-27	102507101	5-9	102522605	2-3
102400102	1-25, 1-27	102508202	1-13	102522608	2-3, 2-5
102400202	1-21	102508401	12-9	102522609	2-3, 2-5
102400302	1-21	102508601	12-3	102522701	12-15
102406701	8-3	102508701	12-3	102522901	6-3, 12-3
102430901	7-13	102508901	1-27	102523101	1-7
102431001	7-11	102508902	1-25	102523901	1-9
102453001	11-5	102509301	5-19	102526201	11-3
102453101	11-5	102509701	12-13	102526401	12-13
102500001	4-13	102509801	12-13	102526801	12-13
102500101	4-11	102510001	12-3	102527501	3-5
102500501	1-19	102510101	12-7	102528501	4-13
102500601	1-19	102510201	12-13	102528601	4-11
102500801	4-7, 4-9	102510601	12-13	102531001	1-31, 1-33, 1-35, 1-37
102501401	1-19	102510802	12-15	102531402	1-31, 1-33, 1-35, 1-37
102501402	1-19	102510901	12-9	102531501	1-29, 1-33, 1-35, 1-37
102501501	1-5	102511101	12-9	102531601	1-31, 1-33, 1-35, 1-37
102502301	1-19	102511301	12-13	102531701	1-29, 1-33
102502302	1-19	102511302	12-13	102531702	1-29, 1-35
102502304	1-19	102511601	1-27	102531704	1-29, 1-37
102502305	1-19	102511602	1-25	102534001	12-13
102502306	1-19	102511702	1-11	102534201	1-3, 1-31, 1-33, 1-35, 1-37
102502307	1-19	102512001	11-9	102534404	1-5
102502308	1-19	102512401	1-25, 1-27	102534801	1-33, 1-35, 1-37, 5-21
102502309	1-19	102513001	5-17	102536601	6-3, 12-3
102502311	1-19	102513102	4-7, 8-9	102536602	6-3
102502313	1-19	102513301	1-25, 1-27	102536603	12-3
102502401	1-5	102513501	1-25, 1-27	102536604	6-3
102502402	1-5	102514201	8-3	102536605	12-3
102502404	1-5	102514401	1-11, 8-11	102538101	3-3
102502405	1-5	102514601	11-9	102538201	3-5
102502406	1-5	102514701	8-3	102538601	12-9
102502407	1-5	102515001	6-3, 6-13	102540301	7-15
102502408	1-5	102515101	6-3	102540601	2-5
102502409	1-5	102515301	11-9	102540701	2-5
102502411	1-5	102515401	11-3	102540901	3-3, 3-5
102502413	1-5	102515501	11-9	102541425	1-29, 1-33, 1-35, 1-37
102502501	1-5	102515601	11-9	102543902	1-21
102502901	1-19	102516301	1-23	102544001	1-21
102503001	1-19	102516901	1-13	102544101	1-21
102503221	1-17, 1-29, 1-33	102517001	1-17	102544201	1-21, 1-25, 1-27
102503222	1-17, 1-29, 1-35	102517801	3-3	102544901	1-33, 1-35, 1-37, 5-21
102503224	1-17, 1-29, 1-37	102517901	3-3	102550301	12-7
102503225	1-17, 1-29	102518001	3-5	102551701	1-17
102503901	1-17	102518101	3-5	102551901	4-7, 4-9
102504001	1-17	102518301	3-5	102552001	4-7, 4-9
102504101	1-17	102519201	3-3	102554901	11-9

INDEX

102555501	16-3	102584701	1-31, 1-33, 1-35, 1-37	103199301	1-25, 1-27
102555901	3-5	102584801	1-31, 1-33, 1-35, 1-37	103200301	1-25, 1-27
102556701	2-5	102585801	12-7	103205101	1-25, 1-27
102556801	2-5	102585901	9-3	103209501	5-7
102557201	1-7	102586201	6-9	103210101	1-25, 1-27
102557801	2-3, 2-5	102587401	4-11, 4-13	103226201	12-11
102558201	8-11	102587501	4-11, 4-13	103226301	12-11
102558301	8-11	102588301	8-11	103226401	12-11
102558401	8-11	102588501	5-17, 5-19, 5-21	103226601	12-11
102558501	8-11	102588601	5-13	103226701	12-11
102558601	8-11	102588701	4-11, 4-13	103238501	3-5
102558701	8-11	102588901	4-11, 4-13	103262001	12-15
102558801	4-11, 4-13	102590001	12-7	103325501	13-5
102558901	4-11, 4-13	102594301	4-7, 4-9	103325601	13-5
102559001	4-11, 4-13	102601501	16-5	103325701	13-5
102559101	4-11, 4-13	102603501	16-5	103325801	13-5
102559301	4-11, 4-13	102605201	16-5	103327601	1-17
102559401	4-11, 4-13	102606101	16-5	103327701	4-11
102559601	4-11, 4-13	102607501	16-5	103327901	4-13
102559701	4-11, 4-13	102668801	16-9	103330601	1-3
102560201	1-27	102669901	16-7	103337601	13-5
102560202	1-25	102674001	16-5	103344301	4-11, 4-13
102560301	1-25, 1-27	102674101	16-5	103345701	10-3
102562401	16-3	102674201	16-5	103372101	8-3
102562701	1-15	102674401	16-9	103372301	8-3
102562801	1-15	102674601	16-9	103379601	11-11
102562901	1-15	102675001	16-5	103380201	4-3
102563001	4-11, 4-13	102675101	16-5	103380202	4-3
102563101	4-11, 4-13	102675201	16-5	103388501	5-13
102564901	5-11	102675301	16-5	103397901	15-5, 15-7
102565101	5-11	102675401	16-5	103403201	12-15
102565201	5-11	102686101	16-3	103414901	15-5, 15-7
102565301	5-11	102704701	13-7, 13-9	103423001	1-15
102565401	5-11	102704801	13-7, 13-9	103423002	1-15
102565701	5-11	102704901	13-7, 13-9	103423004	1-15
102565801	5-11	102705001	13-7	103428501	15-3
102565901	5-11	102753401	7-9	103428601	15-3
102566001	5-11	102771701	14-3	103428701	15-3
102566101	5-11	102803301	6-5	103429001	15-3
102568701	1-17	102806201	12-15	103429101	15-3
102569304	2-3	102865101	8-3	103429201	15-3
102569309	2-3, 2-5	102878101	5-15	103429301	15-3
102570401	16-11	102878201	5-13, 5-15	103429501	15-3
102570901	1-33	102886301	14-3	103429701	15-3
102570902	1-35	102886401	14-3	103434001	15-3
102570904	1-37	102886501	14-3	103439901	15-3
102572201	1-29, 1-33, 1-35, 1-37	102886601	14-3	103447901	1-15
102572401	12-3	102956201	5-13, 5-15	103477901	5-15
102573101	1-29, 1-33, 1-35, 1-37	102956301	12-11	103483101	4-3
102574801	1-29, 1-33, 1-35, 1-37	102956401	12-11	103483102	4-3
102574901	1-29, 1-33, 1-35, 1-37	102956501	12-11	103483201	4-3
102575101	1-29, 1-33, 1-35, 1-37	102958001	12-11	103483301	4-3
102575201	1-29, 1-33, 1-35, 1-37	102967901	1-19	103483401	4-3
102576801	12-9	102973801	5-15	103483501	4-3
102577001	12-13	103010101	8-3	103483601	4-3
102577002	12-13	103196001	1-25, 1-27	103483701	4-3

INDEX

103512801 15-3
 103512901 15-3
 103513001 15-3
 103517401 15-3
 103517601 15-5
 103528501 4-5
 103528601 4-5
 103528701 4-5
 103528702 4-5
 103535001 4-5, 4-7, 4-9
 103655002 8-3
 103677401 1-19
 103677402 1-19
 103711001 5-15
 103717001 15-3
 103717002 15-3
 103717003 15-3
 103724503 5-3
 103724601 5-3
 103724901 5-3
 103744901 4-9
 103745001 4-9
 103777001 8-3
 103779601 15-3
 103781101 8-3
 103781201 8-3
 103783002 5-3
 103783003 5-3
 103783004 5-3
 103796701 5-3
 103797301 5-3
 103810201 5-7
 103816601 1-5
 96704416 7-15

A

absorber, front shock 5-13
 absorber, rear shock 5-17, 5-19, 5-21
 AC cord 15-5, 15-7, 15-9, 15-11
 AC cord bushing 15-3, 15-5
 AC cord receptacle 15-11
 AC cordset 15-3
 accelerator cable 4-7, 8-9
 accelerator pedal 4-11, 4-13
 accelerator pedal adjustment tool 16-3
 accelerator pedal pad 4-11, 4-13
 access panel 1-19
 adapter
 cable (IQDM) 16-7
 adhesive, guide ring 16-3
 adjuster
 hydraulic brake 16-7
 adjuster, lash 7-11
 air filter 8-11
 air filter canister evacuation valve 8-11
 air intake assembly 8-11

air intake cover 8-11
 air intake hose 8-11
 ammeter 15-3, 15-5, 15-7, 15-9, 15-11
 arbor 16-3
 arm
 governor 11-3
 pivot 11-3
 rocker 7-9
 armature 6-15, 13-3, 13-5, 13-7, 13-9
 armature conversion kit 6-15
 armrest 1-15, 1-29, 1-33, 1-35, 1-37
 assembly
 armature 6-15
 axle 11-7
 brake lever 4-3
 brush connector 6-15
 brush holder 6-15
 carburetor 8-5
 connecting rod 7-13
 cylinder head 7-9
 drive hub 10-3
 driven clutch 10-7
 driven clutch fixed-face 10-7
 field coil 6-15
 float 8-5
 frame and field (motor) 13-7, 13-9
 fuel tank vent 8-3
 governor 11-5
 idle screw 8-5
 moveable-face 10-3, 10-7
 pilot air screw 8-5
 plug cap 7-5
 score card plate 5-5
 secondary clutch weight 10-3

axle 11-7, 14-3
 axle shaft oil seal 11-7, 14-3
 axle tube 14-3

B

backrest 1-17, 1-29, 1-33, 1-35, 1-37
 bag hoop 1-17
 bag strap 1-17
 bag strap buckle 1-17
 bag, desiccant 10-3
 ball bearing 7-11
 ball joint 5-11
 ball stud 11-9
 ball, bearing 5-11, 5-15
 ball, shifter 11-5
 ball, steel pressure relief 7-7
 band, RPM limiter mount 7-5
 barb, vent 8-3
 barrel, plastic 1-7, 1-9, 1-17, 1-29, 1-31, 1-33, 1-35, 1-37, 4-7, 4-9
 battery 6-5
 battery cable 12-13

battery cap, 6-volt 12-13
 battery charger 15-5, 15-7, 15-9, 15-11
 battery charger case 15-5, 15-7, 15-9, 15-11
 battery charger handle 15-5
 battery charger receptacle 12-13
 battery charger transformer 15-5, 15-7, 15-9, 15-11
 battery clamp 6-5
 battery condition indicator 12-3
 battery discharge machine 16-3
 battery light 12-3
 battery terminal protector spray 16-3
 battery thermometer 16-3
 battery, 12-volt, Trojan T1275, moist 12-13
 battery, 12-volt, Trojan T1275, wet 12-13
 bearing 14-3
 ball 5-11, 5-15, 7-11
 ball (motor) 13-7, 13-9
 idler 10-3
 inner axle tube 11-7, 14-3
 needle 11-5
 outer axle tube 11-7
 bearing and oil seal remover 16-3
 bearing driver set 16-3
 bearing puller 16-3
 bearing puller wedge 16-3
 bearing retainer 13-3, 13-5
 beauty panel, front 1-5
 beauty panel, rear 1-19
 bellows, steering 5-11
 belt, drive 10-5
 belt, starter/generator 6-17, 10-3
 bezel, FNR 11-9
 body kick plate 1-11, 1-13
 body, front 1-5, 1-19
 body, under 1-19
 bolt, U- 1-33, 1-35, 1-37, 5-21
 boot, switch 12-9
 bottom seat 1-15
 bracket
 accelerator cable 8-9
 adjustable starter/generator 6-17
 governor cable 8-9
 muffler mounting 9-3
 oil filter mount 7-7
 oil level switch 7-11
 relay mounting 15-9
 RPM limiter 7-5
 shock absorber 5-17, 5-19, 5-21
 shock mounting 5-17, 5-19, 5-21
 snubber 7-15
 starter/generator mounting 6-17
 throttle spring return 8-7
 bracket, clamshell 1-9
 brake adjusting mechanism 4-3
 brake adjustment tool 16-3

INDEX

brake cable release tool 16-3
 brake drum 4-3
 brake lever 4-3
 brake pedal 4-11, 4-13
 brake pedal adjustment tool 16-3
 brake pedal pad 4-11, 4-13
 brake pedal tension tool 16-3
 brake return spring 4-11, 4-13
 brake rod 4-11, 4-13
 brake self-adjusting mechanism 4-3
 brake shoe 4-3
 brake spring 4-3
 breaker, circuit 15-3, 15-5, 15-7, 15-9, 15-11
 breather 11-3, 14-3
 brow 1-5
 brow cap 1-5
 brush 13-3, 13-5, 13-7, 13-9
 brush and screw set 6-15
 brush box assembly 13-7, 13-9
 brush connector 6-15
 brush holder 6-15
 brush inspection port cover 6-15
 brush port cover 6-15
 brush rigging 13-3, 13-5, 13-7, 13-9
 brush spring 13-3, 13-5, 13-7, 13-9
 brush spring set 6-15
 bucket, electric vehicle 12-13
 bucket, gas vehicle 8-3
 buckle, bag strap 1-17
 bumper 1-3
 drive unit (motor) 13-3, 13-5, 13-7, 13-9
 jounce 1-33, 1-35, 1-37, 5-21
 jounce, bracket 1-33, 1-35, 1-37, 5-21
 bushing 5-13, 5-15, 5-17, 5-19, 5-21, 10-3
 AC cord 15-3, 15-5
 return line 8-3
 bushing, insulated 13-3, 13-5
 button, drive 10-7
 buzzer, reverse 6-3, 12-3

C

cable
 accelerator 4-7, 8-9
 governor 8-9
 IQDM 16-7
 cable support bracket 11-9
 cable, battery 12-13
 calibration test module 16-3
 cam
 driven clutch 10-7
 neutral lockout 11-9
 cam installation tool 16-3
 camshaft 7-11
 camshaft shim 7-11
 canopy 1-25, 1-27
 canopy bracket 1-19

canopy component kit 1-27
 canopy cover 1-21, 1-25, 1-27
 canopy drain cover 1-25, 1-27
 canopy handle 1-25, 1-27
 canopy hardware 1-25, 1-27
 canopy support 1-25, 1-27
 cap
 battery, 6-volt 12-13
 dust 12-3
 key switch 6-3, 12-3
 plug 7-5
 cap, SAM 1-21
 carburetor 8-5
 carburetor float level tool 16-7
 carburetor gasket 8-7
 carburetor insulator 8-7, 13-3, 13-5
 carburetor mounting gasket 8-7
 card, safety first 16-9
 case
 battery charger 15-5, 15-7, 15-9, 15-11
 differential gear 11-7
 gear 11-3, 14-3
 rocker 7-9
 case, charger 15-3
 charger bezel tool 16-3
 charger board relay 15-3
 charger case 15-3
 charger hardware 15-3
 charger legs 15-3
 charger, battery 15-5, 15-7
 choke botton rod 1-11, 8-11
 choke lever 1-11, 8-11
 circuit breaker 15-3, 15-5, 15-7, 15-9, 15-11
 clamp
 battery 6-5
 cable retaining 8-9
 hose 8-3, 8-7
 muffler hose 9-3
 clamshell bracket 1-9
 clip, body trim 1-9, 1-19
 clip, score card 5-3, 5-5
 closeout 12-13
 cluster idler gear 11-5
 clutch alignment tool 16-5
 clutch pulley 10-3
 clutch removal tool 16-3
 clutch repair kit 10-7
 clutch tool kit 16-5
 clutch weight 10-3
 clutch, drive 10-3
 clutch, driven 10-7
 coil, field 6-15
 coil, ignition 7-5
 collet 7-9
 column, steering 5-7, 5-9
 communication display module 16-5

component mounting plate 12-15
 compression gauge 16-5
 compression spring 1-11, 8-11
 compressor, piston ring 16-9
 compressor, valve spring 16-11
 computer, v 3.0 onboard 12-15
 connecting rod 7-13
 connector tube, handrail 1-29, 1-33, 1-35, 1-37
 connector, 9-pin 6-3, 6-13, 12-3
 connector, a- 6-15
 continuity tester 16-5
 controller, motor speed 12-15
 controller, speed 12-15
 cord connector 7-11
 cord set, DC 15-5
 cord, AC 15-5, 15-7, 15-9, 15-11
 cord, DC 15-7, 15-9, 15-11
 Cordset
 PD3, AC 114" 15-3
 PD3, AC 80" 15-3
 PD3, DC 113" 15-3
 PD3, DC 154" 15-3
 PD3, DC 205" 15-3
 counterbalance guide shaft 7-13
 counterbalance weight 7-13
 coupler, SPWS 12-11
 cover
 air intake 8-11
 brush inspection port 6-15
 brush port 6-15
 crankcase 7-11
 electronics module 12-9
 oil pump 7-7
 cover plate 13-7, 13-9
 cover, canopy drain 1-25, 1-27
 cover, drain 1-23
 crankcase 7-13
 crankcase cover 7-11
 crankcase vent tube 8-7
 crankshaft 7-13
 crankshaft rod 7-13
 crankshaft shim 7-13
 current limiter 15-11
 cushion, shock absorber 5-17, 5-19, 5-21
 cutter, valve seat 16-5, 16-11

D

damper, RPM limiter 7-5
 dash 1-7
 dash support assembly 5-13
 dash tray 1-7
 DC cord 15-7, 15-9, 15-11
 DC cord set 15-5
 DC cordset 15-3
 decal
 battery weight warning 3-5

INDEX

Club Car clip 3-3, 3-5
 component mounting plate 3-5
 electrical cover safety 3-5
 four-passenger warning 1-33, 1-35, 1-37, 3-7
 frame ground warning 3-3
 gas and governor warning 3-3
 IR/Club Car 1-9
 on/off 3-3, 3-5
 operating instructions 3-3, 3-5
 operating instructions (electric) 3-5
 operating instructions (gas) 3-3
 private speed mode 3-5
 rollover warning 3-3, 3-5
 rotating parts 3-3
 Tow/Run switch 3-5
 warning, battery weight 3-5
 desiccant bag 10-3
 DF-terminal insulator 6-15
 diesel tachometer probe 16-9
 differential
 drive unit 14-3
 differential gear 11-7, 14-3
 differential gear case 11-7
 differential housing 14-3
 differential idler gear 11-7
 differential pin 11-7
 diode 12-9
 diode, tow switch 12-7
 dipstick 7-3
 drain cover 1-23
 drain plug 7-7
 drain plug gasket 7-7, 11-3
 drive belt 10-5
 drive button 10-7
 drive clutch 10-3
 drive clutch button 10-3
 drive clutch fixed sheave tool 16-5
 drive clutch fixed-face 10-3
 drive clutch holder tool 16-5
 drive clutch hub puller 16-5
 drive clutch puller 16-5
 drive clutch spider removal tool 16-5
 drive clutch spring 10-3
 drive clutch weight 10-3
 drive hub 10-3
 drive unit bumper 13-3, 13-5, 13-7, 13-9
 driven clutch 10-7
 driven clutch button 10-7
 driven clutch cam 10-7
 driven clutch cam puller 16-5
 driven clutch fixed-face assembly 10-7
 driven clutch puller plug 16-5
 driven clutch spring compression base tool 16-5
 driven clutch spring compression collar tool

16-5
 driven clutch spring compression nut tool 16-5
 driver, drive clutch 10-3
 drum, brake 4-3
 dry moly lubricant 16-7
 dust cap 12-3
 dust seal 5-11

E

eccentric adjustment screw 5-15
 end bell, commutator 6-15
 end bell, output shaft 6-15
 end cap, motor 13-3, 13-5, 13-7, 13-9
 end shield
 motor 13-3, 13-5
 end, tie rod 5-11
 engine mounting plate 7-15
 engine shroud 7-3
 engine, FE350 CW without ACR 7-3
 exhaust system 9-3
 exhaust valve 7-9

F

face, moveable 10-3, 10-7
 fan housing 7-3
 fan shroud 7-3
 fan, flywheel 7-5
 fascia 1-5
 field coil 6-15
 field coil housing 6-15
 fill plug 11-3
 filter
 air 8-11
 fuel 8-3
 oil 7-7
 oil pump 7-7
 fixed-face, drive clutch 10-3
 fixed-face, driven clutch 10-7
 float 8-5
 floor cover plate 4-7, 4-9
 floor mat 1-31, 1-33, 1-35, 1-37
 floormat 1-9
 floormat retainer 1-9
 flywheel 7-5
 flywheel fan 7-5
 flywheel fan plate 7-5
 flywheel puller 16-7
 FNR bezel 11-9
 FNR handle 11-9
 FNR housing 12-9
 FNR shift lever 11-3
 FNR shifter 11-9
 FNR shifter base 11-9
 foot deck 1-31, 1-33, 1-35, 1-37
 fork, shift 11-5

four-passenger conversion kit 1-33, 1-35
 four-passenger kit 1-37
 frame and field assembly (motor) 13-7, 13-9
 front body 1-5, 1-19
 front body, beauty panel 1-5
 front suspension structure 5-13
 F-terminal hardware 6-15
 f-terminal insulator 6-15
 fuel filter 8-3
 fuel line 8-3, 8-7
 fuel tank hold-down 8-3
 fuel tank vent 8-3
 fuse 15-7, 15-9, 15-11
 10-amp 6-5
 15-amp 12-9
 charger 15-3, 15-5
 fuse cover, sealed 6-5

G

gasket 14-3
 air intake 8-11
 carburetor 8-7
 carburetor mounting 8-5, 8-7
 crankcase cover 7-9, 7-11
 drain plug 7-7, 11-3
 exhaust 7-9, 9-3
 head 7-9
 insulator 7-9, 8-7
 liquid 11-3, 14-3, 16-7
 rocker case 7-9
 gasket kit, FE350 7-9
 gauge, compression 16-5
 GCOR 4-11
 gear
 case 11-3, 14-3
 cluster idler 11-5
 differential 11-7, 14-3
 differential idler 11-7, 14-3
 differential output 14-3
 helical 7-13, 11-5, 11-7
 spur 7-13, 11-5
 steering 5-11
 synchro 11-5
 gear yoke 16-7
 governor 11-5
 governor arm 11-3
 governor cable 8-9
 governor cable bracket 8-9
 governor shaft installation tool 16-7
 governor shield 8-7
 grip, pencil 5-3, 5-5
 grommet 8-3
 guide
 intake valve 7-9
 valve 7-9
 valve seat cutter 16-11

INDEX

guide ring adhesive 16-3

H

hand rail 1-31, 1-33, 1-35, 1-37
handle, battery charger 15-5
handle, FNR 11-9
handrail connector tube 1-29, 1-33, 1-35, 1-37
hardware kit, charger 15-3
hardware, F-terminal 6-15
harness, instrument panel 6-3, 6-13, 12-3
harness, wire 6-9, 12-7
head gasket 7-9
head, cylinder 7-9
heatsink 12-15, 15-5
heatsink and rectifier 15-7, 15-9, 15-11
helical gear 7-13, 11-5, 11-7
hip restraint 1-15, 1-29, 1-33, 1-35, 1-37
hold-down, fuel tank 8-3
hoop, bag 1-17
hose, air intake 8-11
hose, fuel 8-3
hose, SPWS 12-11
housing
 3-pin 13-3, 13-5, 13-7, 13-9
 differential 14-3
 fan 7-3
 field coil 6-15
hub 5-15
hub, synchronizer clutch 11-5
hubcap 5-15
hydraulic brake adjuster 16-7
hydrometer 16-7

I

idle screw assembly 8-5
idler bearing 10-3
idler gear, differential 14-3
ignition coil 7-5
inner frame snubber 7-15
input shaft 14-3
insert, synchronizer 11-5
instrument panel 6-3, 12-3
instrument panel harness 6-3, 6-13, 12-3
insulated bushing 13-3, 13-5
insulator gasket 7-9, 8-7
insulator, carburetor 8-7, 13-3, 13-5
intake assembly 8-11
intake cover 8-11
intake hose 8-11
intake pipe 8-7
intake valve 7-9
intermediate shaft 14-3
internal retaining ring pliers 16-7
IQ display module (IQDM) 16-7

J

J-clip 1-19
jet, main 8-5
jet, pilot 8-5
joint
 ball 5-11
jounce bumper 1-33, 1-35, 1-37, 5-21
jounce bumper bracket 1-33, 1-35, 1-37, 5-21

K

key
 crankshaft 7-5, 7-13
 driven clutch 10-7
 On/Off 6-3, 12-3
 square 10-7
 starter/generator 6-15
 woodruff 11-3
key switch 6-3, 12-3
key switch cap 6-3, 12-3
kick plate 1-11
kick plate, body 1-11, 1-13
king pin 5-15
kit
 3-pin housing 13-3, 13-5, 13-7, 13-9
 brake pedal adjustment tool 16-3
 canopy component 1-27
 clutch repair 10-7
 differential gear case 11-7
 drive clutch button 10-3
 drive clutch weight 10-3
 driven clutch button 10-7
 four-passenger 1-37
 front hub replacement 5-15
 IQ display module (IQDM) 16-7
 magnet and bearing 13-3, 13-5
 motor brush 13-7, 13-9
 motor brush spring 13-7, 13-9
 motor cover plate 13-7, 13-9
 motor speed sensor 13-7, 13-9
 motor terminal hardware 13-7, 13-9
 neutral lockout cam 11-9
 PD3 Cordest, AC 114" 15-3
 PD3 Cordest, AC 80" 15-3
 PD3 Cordest, DC 113" 15-3
 PD3 Cordest, DC 154" 15-3
 PD3 Cordest, DC 205" 15-3
 PD3 hardware 15-3
 shock absorber cushion 5-17, 5-19, 5-21
 SPWS (single-point watering system) 12-11
 tune-up 16-9

L

lash adjuster 7-11
L-bracket, motor 13-7

leaf spring 1-33, 1-35, 1-37, 5-17, 5-19, 5-21

legs, charger 15-3

lever

 change 11-3
 choke 1-11, 8-11

light

 battery 12-3
 oil 6-3

limit switch 11-9

limiter

 current 15-11
 RPM 7-5

line, fuel 8-3, 8-7

liquid gasket 11-3, 14-3, 16-7

low oil warning light 6-3

lubricant, dry moly 16-7

lubricant, moly-teflon 13-3, 13-5, 13-7, 13-9, 16-7

lug nut 2-3, 2-5

lug stud 11-7, 14-3

M

magnet and bearing kit 13-3, 13-5
magnet, speed sensor 13-3, 13-5, 13-7, 13-9
main jet 8-5
manifold, SPWS 12-11
mat, floor 1-9, 1-31, 1-33, 1-35, 1-37
MCOR 4-13
mechanism, brake adjusting 4-3
meter, volt ohm 16-11
module
 calibration test 16-3
 communication display 16-5
moly-teflon lubricant 16-7
motor
 48-volt 13-5
 48-volt IQ 13-3, 13-7, 13-9
motor armature 13-3, 13-5
motor brush 13-3, 13-5
motor brush kit 13-7, 13-9
motor brush spring kit 13-7, 13-9
motor bumper 13-3, 13-5, 13-7, 13-9
motor controller 12-15
motor end cap 13-3, 13-5, 13-7, 13-9
motor end shield 13-3, 13-5
motor L-bracket 13-7
motor magnet, speed sensor 13-3, 13-5, 13-7, 13-9
motor speed controller 12-15
motor speed sensor 13-3, 13-5, 13-7, 13-9
motor speed sensor kit 13-7, 13-9
motor stator shell and winding 13-3, 13-5
motor terminal hardware kit 13-7, 13-9
moveable-face 10-3, 10-7
muffler hose clamp 9-3

INDEX

N

needle bearing 11-5
neutral lockout cam 11-9
nozzle, main 8-5
nut, lug 2-3, 2-5

O

oil filler tube 7-3
oil filter 7-7
oil filter mount bracket 7-7
oil filter screen 7-11
oil filter screen plate 7-11
oil level sensor 7-11
oil level switch bracket 7-11
oil pump and rotor 7-7
oil pump cover 7-7
oil pump filter 7-7
oil pump plate 7-7
oil seal 7-9, 7-11, 7-13, 11-3, 11-5
oil warning light, low 6-3
onboard computer (v 3.0) 12-15
O-ring 7-3, 7-9, 7-11, 7-13, 12-11

P

pad
 accelerator pedal 4-11, 4-13
 brake pedal 4-11, 4-13
 park brake pedal 4-11, 4-13
paint, touch-up 16-7
panel
 SAM 1-17
panel, access 1-19
panel, beauty
 front body 1-5
 rear body 1-19
park brake pad 4-11, 4-13
pedal assembly 4-11, 4-13
pedal group 4-11, 4-13
pedal spring kit 4-11, 4-13
pencil grip 5-3, 5-5
pilot air screw assembly 8-5
pilot jet 8-5
pin, differential 11-7
pin, king 5-15
pin, piston 7-13
pinion, steering 5-11
pipe, intake 8-7
piston 7-13
piston pin 7-13
piston ring 7-13
piston ring compressor 16-9
piston ring pliers 16-9
piston ring set 7-13
pivot arm 11-3
plate

cover 13-7, 13-9
engine mounting 7-15
flywheel fan 7-5
kick 1-11
oil filter screen 7-11
oil pump 7-7
score card 5-5
thrust 11-5, 11-7
plate, component mounting 12-15
plate, floor cover 4-7, 4-9
pliers
 internal retaining ring 16-7
 piston ring 16-9
 retaining ring 16-9
plug
 drain 7-7
 driven clutch puller 16-5
 fill 11-3
 spark 7-5
plug cap 7-5
pole set 6-15
press weldment 16-5
protector spray, battery terminal 16-3
puller
 bearing 16-3
 clutch 16-3
 drive clutch 16-5
 drive clutch hub 16-5
 driven clutch cam 16-5
 flywheel 16-7
 seal 16-9
 special use tool 16-9
pulley
 clutch 10-3
 starter-generator 6-15
push rod 7-9

R

rack and pinion 5-11
rack and pinion steering gear box 5-11
rack, steering 5-11
reaf-facing seat 1-37
reamer, valve guide 16-9
rear body, beauty panel 1-19
receptacle, AC cord 15-11
receptacle, battery charger 12-13
rectifier with heatsink 15-7, 15-9, 15-11
regulator, voltage 6-5
relay 15-9, 15-11
relay mounting bracket 15-9
relay, charger board 15-3
remover, bearing and oil seal 16-3
resistor 12-15
restraint, hip 1-15, 1-29, 1-33, 1-35, 1-37
retainer
 bearing 13-3, 13-5

shock absorber cushion 5-17, 5-19, 5-21
spring (drive clutch) 10-3
valve spring 7-9
retainer, floormat 1-9
retaining ring pliers 16-9
return spring, brake 4-11, 4-13
reverse buzzer 6-3, 12-3
rigging, brush 13-3, 13-5
ring
 piston 7-13
 retaining 10-3, 10-7, 11-9
 snap 7-9, 7-13
 spiral backup 10-3
 synchronizer 11-5
ring, piston 7-13
rocker arm 7-9
rocker case 7-9
rocker case gasket 7-9
rocker shaft 7-9
rocker switch 12-9
rod
 brake 4-11, 4-13
 connecting 7-13
 crankshaft 7-13
 push 7-9
 shift 11-5
rotor, oil pump and 7-7
RPM limiter 7-5
RPM limiter bracket 7-5
RPM limiter damper 7-5
RPM limiter mount band 7-5

S

safety first card 16-9
SAM 1-17
SAM (structural accessory module) 1-17
SAM cap 1-21
SAM panel 1-17
score card clip 5-3, 5-5
score card plate 5-5
screen, oil filter 7-11
screw, eccentric adjustment 5-15
screw, valve clearance adjuster 16-9
seal
 dust 5-11
 lip 14-3
 oil 7-9, 7-11, 7-13, 11-3, 11-5, 11-7, 14-3
seal puller 16-9
sealant 11-3, 14-3
seat
 spring 7-9
 valve 7-7
seat bottom 1-15, 1-29, 1-33, 1-35, 1-37
seat bracket 1-29, 1-33, 1-35, 1-37
sensor, motor speed 13-3, 13-5, 13-7, 13-9
sensor, oil level 7-11

INDEX

- sensor, speed 13-3, 13-5
 - set, brush and screw 6-15
 - set, pole 6-15
 - shackle 5-17, 5-19, 5-21
 - shaft
 - change 11-3
 - counterbalance guide 7-13
 - input 14-3
 - intermediate 14-3
 - rocker 7-9
 - transmission 11-5
 - shield, governor 8-7
 - shift fork 11-5
 - shift lever 11-3
 - shift rod 11-5
 - shifter, FNR 11-9
 - shim, camshaft 7-11
 - shim, crankshaft 7-13
 - shock absorber (front) 5-13
 - shock absorber (rear) 5-17, 5-19, 5-21
 - shock absorber cushion 5-17, 5-19, 5-21
 - shock absorber cushion retainer 5-17, 5-19, 5-21
 - shock mounting bracket 5-17, 5-19, 5-21
 - shoe, brake 4-3
 - shroud 7-3
 - shroud, engine 7-3
 - shroud, fan 7-3
 - single-point watering system 12-11
 - sleeve 5-13, 5-15, 5-17, 5-19, 5-21
 - governor 11-5
 - synchronizer 11-5
 - snap ring 7-9, 7-13
 - snubber bracket 7-15
 - snubber, inner frame 7-15
 - solenoid, 12-volt 6-5
 - solenoid, 48-volt 12-15
 - spanner wrench 16-9
 - spark plug 7-5
 - speed controller 12-15
 - speed sensor 13-3, 13-5, 13-7, 13-9
 - speed sensor magnet 13-3, 13-5, 13-7, 13-9
 - speed sensor, motor 13-3, 13-5, 13-7, 13-9
 - spindle 5-15
 - spiral backup ring 10-3
 - spray, battery terminal protector 16-3
 - spring
 - brake return 4-11, 4-13
 - brush 6-15, 13-3, 13-5, 13-7, 13-9
 - compression 1-11, 5-3, 5-5, 8-11
 - drive button 10-3
 - drive clutch 10-3
 - driven clutch 10-7
 - forward/reverse cam 11-9
 - leaf 1-33, 1-35, 1-37, 5-17, 5-19, 5-21
 - shifter 11-5
 - synchronizer 11-5
 - throttle return 8-7
 - valve 7-9
 - spur gear 7-13, 11-5
 - SPWS 12-11
 - SPWS (single-point watering system) kit 12-11
 - SPWS coupler 12-11
 - SPWS fitting, swivel T 12-11
 - SPWS hose 12-11
 - SPWS manifold 12-11
 - SPWS tubing 12-11
 - stand-offs, plastic 15-3
 - starter/generator 6-15
 - starter/generator belt 6-17, 10-3
 - starter/generator pulley 6-15
 - stator shell and winding 13-3, 13-5
 - steel pressure relief ball 7-7
 - steering column 5-7, 5-9
 - steering column bearing press tool 16-9
 - steering column retaining ring tool 16-9
 - steering gear 5-11
 - steering pinion 5-11
 - steering rack 5-11
 - steering wheel puller tool 16-9
 - steering, rack and pinion gear box 5-11
 - stem, valve 2-3, 2-5
 - stiffener, flywheel side 7-15
 - stiffener, PTO side 7-15
 - strap, bag 1-17
 - stud 7-15
 - lug 11-7, 14-3
 - stud, ball 11-9
 - suppressor, voltage 15-7, 15-9, 15-11
 - suspension, front structure 5-13
 - switch
 - four-position 15-9, 15-11
 - key 6-3, 12-3
 - limit 11-9
 - rocker 12-9
 - Tow/Run 12-9
 - switch rubber boot 12-9
 - synchro gear 11-5
 - synchronizer clutch hub 11-5
 - synchronizer insert 11-5
 - synchronizer sleeve 11-5
 - synchronizer spring 11-5
- T**
- 12-volt solenoid 6-5
 - tachometer 16-9
 - tachometer probe, diesel 16-9
 - tester, continuity 16-5
 - thermometer, battery 16-3
 - throttle return spring 8-7
 - throttle spring return bracket 8-7
 - thrust plate 11-5, 11-7
- tie rod end 5-11**
- tire 2-3, 2-5**
- tire, pro tour, 205-50 x 10 2-5**
- tool**
- accelerator pedal adjustment 16-3
 - belt tensioning, starter/generator 16-11
 - brake adjustment 16-3
 - brake cable release 16-3
 - brake pedal adjustment 16-3
 - brake pedal tension 16-3
 - cam installation 16-3
 - carburetor float level 16-7
 - charger bezel 16-3
 - clutch alignment 16-5
 - cT-wrench 16-5
 - drive clutch fixed sheave 16-5
 - drive clutch holder 16-5
 - drive clutch spider removal 16-5
 - driven clutch spring compression base 16-5
 - driven clutch spring compression collar 16-5
 - driven clutch spring compression nut 16-5
 - governor shaft installation 16-7
 - puller, special use 16-9
 - steering column bearing press 16-9
 - steering column retaining ring 16-9
 - steering wheel puller 16-9
 - transaxle axle seal 16-9
 - transaxle pinion seal 16-9
 - transmission 16-9
 - valve guide driver 16-9
 - valve seat cutter 16-5
- tool kit, clutch 16-5**
- touch-up paint 16-7**
- tow switch diode 12-7**
- Tow/Run switch 12-9**
- transaxle 14-3**
- transaxle axle seal tool 16-9**
- transaxle housing 14-3**
- transaxle pinion seal tool 16-9**
- transaxle, unitized 11-3**
- transformer, battery charger 15-5, 15-7, 15-9, 15-11**
- transmission shaft 11-5**
- transmission tool 16-9**
- tube**
- crankcase vent 8-7
 - oil filler 7-3
- tubing, SPWS 12-11**
- tune-up kit 16-9**
- T-wrench tool 16-5**
- U**
- U-bolt 1-33, 1-35, 1-37, 5-21
 - u-bolt 5-17, 5-19

INDEX

underbody 1-19
underbody cover 1-29, 1-33, 1-35, 1-37
underbody cover kit 1-21
unitized transaxle 11-3

V

valve
 exhaust 7-9
 intake 7-9
 reed 7-9
valve clearance adjuster screw 16-9
valve guide 7-9
valve guide driver tool 16-9
valve guide reamer 16-9
valve guide, intake 7-9
valve seat 7-7
valve seat cutter 16-5, 16-11
valve seat cutter guide 16-11
valve seat cutter tool 16-5
valve seat t-wrench 16-11
valve spring 7-9
valve spring compressor 16-11
valve spring retainer 7-9
valve stem 2-3, 2-5
vent barb 8-3
volt ohm meter 16-11
voltage regulator 6-5
voltage suppressor 15-7, 15-9, 15-11

W

warning light, low oil 6-3
watering system, single-point 12-11
wedge, bearing puller 16-3
weight
 clutch 10-3
 counterbalance 7-13
 secondary clutch 10-3
weldment
 press 16-5
wheel 2-3, 2-5
wheel and tire 5-5
wire harness 6-9, 12-7
woodruff key 11-3
wrench, spanner 16-9

Y

yoke support 5-11
yoke, gear 16-7



Club Car, Inc.
P.O. Box 204658
Augusta, GA 30917-4658
USA

Web	www.clubcar.com
Phone	1.706.863.3000 1.800.ClubCar
Int'l	+1 706.863.3000
Fax	1.706.863.5808